

# *Digital Still Camera*

---

## **Operating Instructions**

Before operating the unit, please read this manual thoroughly, and retain it for future reference.

## **Owner's Record**

The model and serial numbers are located on the bottom. Record the serial number in the space provided below. Refer to these numbers whenever you call upon your Sony dealer regarding this product.

Model No. DKC-FP3

Serial No. \_\_\_\_\_



MEMORY STICK

## **DKC-FP3**

## WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

### CAUTION

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the manufacturer.

Dispose of used batteries according to the manufacturer's instructions.

### For the customers in the U.S.A.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

The shielded interface cable recommended in this manual must be used with this equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules.

### For the Customers in the U.S.A. and CANADA

#### DISPOSAL OF LITHIUM ION BATTERY.

##### LITHIUM ION BATTERY.

##### DISPOSE OF PROPERLY.

You can return your unwanted lithium ion batteries to your nearest Sony Service Center or Factory Service Center.

Note: In some areas the disposal of lithium ion batteries in household or business trash may be prohibited.

For the Sony Service Center nearest you call 1-800-222-SONY (United States only).

For the SONY Factory Service Center nearest you call 416-499-SONY (Canada only).

**Caution:** Do not handle damaged or leaking lithium ion batteries.

#### Declaration of Conformity

Trade Name: SONY  
Model No.: DKC-FP3  
Responsible Party: Sony Electronics Inc.  
Address: 1 Sony Drive, Park Ridge, NJ. 07656 USA  
Telephone No.: 201-930-6970

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

# Contents

<b>Battery Safety Precautions .....</b>	<b>5</b>
---	----------

<b>Operation Precautions .....</b>	<b>6</b>
------------------------------------	----------

<b>To Maintain the Efficiency of the Camera .....</b>	<b>7</b>
---	----------

<b>Please Read This .....</b>	<b>8</b>
-------------------------------	----------

<b>Checking the Supplied Accessories .....</b>	<b>10</b>
--	-----------

<b>Features .....</b>	<b>12</b>
-----------------------	-----------

## Locations and Functions of Parts

Front .....	14
Rear .....	15
Top .....	18
Bottom .....	20
LCD Panel .....	21
LCD Monitor .....	22
Viewfinder .....	23

## Preparations

Charging the Battery Pack .....	24
Installation of the Battery Pack .....	25
Setting the Time and Date .....	27
Preparing the Card .....	29
Initializing a Card .....	31
Attaching the Viewfinder Cap .....	32

## Taking a Picture

Taking Pictures .....	33
Locking the Focus .....	36
Setting the Focus Manually .....	37

## Viewing

Checking the Picture Content .....	39
Viewing Pictures on a Television .....	44
Using a PC Card Reader .....	44
Using the PC Card/Parallel Port Adaptor .....	45

## Advanced Operations

### Settings

Choosing the Exposure Mode .....	51
Choosing Picture Size .....	53
Choosing the Picture Quality Mode .....	54
Choosing the Picture Taking Brightness (EV compensation) .....	56
Adjusting for Natural Color Tone (White Balance Adjustment) .....	57
Changing the ISO Sensitivity .....	59
Choosing a Light Metering Method .....	60
Resetting the Content of the Setting .....	62
Saving the Content of Settings .....	63
Reading the Saved Settings .....	64
Making a Folder to Save Pictures .....	65
Attaching Keywords (ID Numbers) to Pictures .....	66
Choosing a Method to Attach a File Name to a Picture .....	71
Miscellaneous Settings .....	73

### Taking a Picture

Shooting with the Flash .....	78
Adjusting White Balance when Taking Pictures with the Flash .....	80
Continuous Shooting .....	82
Taking a Picture at Regular Intervals (Interval Shooting) .....	84
Taking a Picture with the Self-Timer .....	85
Checking Pictures Directly After Shooting (Review Function and Histogram) .....	86

---

## **Playback**

Rotating the Picture .....	87
Viewing an Enlarged Picture .....	88
Checking the Histogram of a Picture .....	90

## **Erasing**

Erasing All Pictures .....	91
Erasing Selected Pictures .....	92
Erasing Pictures during Playback .....	94
Making it Impossible to Erase Important Pictures (Protect) .....	96

## **Miscellaneous**

Setting the LCD Monitor Display .....	98
Adjusting Picture Display on the LCD Monitor .....	100
Operation by Remote Control .....	102
Using a Wall Socket .....	104
Connecting to the PC .....	105

<b>Menu Summary .....</b>	<b>107</b>
---------------------------	------------

<b>Maintenance .....</b>	<b>112</b>
--------------------------	------------

<b>Troubleshooting .....</b>	<b>113</b>
------------------------------	------------

<b>Warning Indicators .....</b>	<b>116</b>
---------------------------------	------------

<b>Error Messages .....</b>	<b>119</b>
-----------------------------	------------

<b>Specifications .....</b>	<b>121</b>
-----------------------------	------------

<b>Index .....</b>	<b>124</b>
--------------------	------------

# Battery Safety Precautions

---

Follow the safety advice below to avoid leakage, internal heating, fires, explosions or accidental ingestion of batteries.

## **DANGER (This applies only to battery packs)**

- Only charge the battery with the supplied charger.
- Do not put the battery into fire. Do not short it out or disassemble it.  
Do not heat in a microwave or conventional oven. If you carry or store the battery with metal objects such as coins or hairpins, shorts may occur.
- Do not recharge or leave the battery pack near fire or under the hot sun.
- If you accidentally get liquid that has leaked from the battery in your eyes, flush with clean water and consult a doctor immediately.

## **WARNINGS**

- Keep the lithium button battery out of the reach of children. In the case of accidental ingestion, consult a doctor immediately.
- Do not put the battery into fire. Do not short it out, disassemble or heat it.
- Use only the specified type of battery.

## **NOTES**

- Be sure the + or - signs are aligned correctly when inserting the battery.
- Remove the battery when it is empty or if the camera is not used for a long time.

If battery leakage occurs, wipe the battery case dry and insert a new battery. If liquid from battery leakage happens to get on your clothes or body, wash well with water.

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the manufacturer.

Dispose of used batteries according to the manufacturer's instructions.

# Operation Precautions

## Places you should not leave your camera

Do not operate or store your camera in places such as those listed below.

Doing so may lead to the breakdown of your camera.

- **Unusually hot places**

If left in very hot places such as under the sun or in a car with the windows closed in summer, warping to the body or breakdown may occur.

- **In direct sunlight or near heating equipment**

Warping or breakdown may occur.

- **Places subject to strong vibrations**

- **Places subject to strong magnetism**

- **Sandy or dusty places**

When using the camera at the seaside, beaches, or otherwise sandy places, take care to keep the camera free of sand particles. Breakdown which might not be able to be repaired may occur.

- **Don't keep the lens or viewfinder pointed toward the sun.**

Direct sunlight can harm the internal components of the digital still camera. Take care when leaving the camera outside or in a window.

## Operation

- **Don't use in places with strong electromagnetic or radial waves.**

You won't be able to correctly record or play back.

- **Don't use near TV, AM radio or FM tuners.**

TV, AM radio or FM tuners will interfere with digital recording.

- **Don't connect the AC power adaptor or battery charger to such devices as electric transformers.**

Internal heating or breakdown may occur.

## Maintenance

If dirty, wipe clean with a soft cloth.

## Care of the camera body

- If the camera is very dirty, wipe with a soft cloth moistened with a thin solution of neutral detergent. Wipe dry with a cloth.
- Do not use alcohol, thinner or benzene on the unit. Such solvents may remove paint from the cabinet.
- When using a chemically treated cloth, follow the manufacturer's instructions.
- If volatile liquids such as insecticide are left for a long time on the rubber or plastic parts, they may remove paint from the cabinet.

## Lens care

Remove dust from the surface of the lens with a blower or soft brush. If the lens is very dirty, wipe with a lens cleaning tissue.

# To Maintain the Efficiency of the Camera

---

## Operating and Storage Places

---

To avoid possible breakdown, do not use or store the camera in the following places:

- Extremely hot or cold places (The operating temperature is 0°C to +40°C (32°F to 104°F))
- In direct sunlight for long periods or near heating equipment
- Humid or dusty places
- Where it is exposed to rain
- Places subject to strong vibrations
- Near sources of strong magnetism
- Near sources of powerful electromagnetic radiation, such as TV or radio transmitters

## Heat Emission

---

Do not wrap the camera in cloth or other materials when operating the camera. Doing so will raise the internal temperature and may cause breakdown.

## Transportation

---

When transporting the camera, pack it in the original carton and packing materials, or similar packaging, to protect it from strong shocks during transportation.

## Care

---

- Use a blower brush to remove dirt or dust from the surface of the lens or viewfinder.
- Lightly wipe the outside surface of the camera with a dry, soft cloth to remove dirt. If the body is very dirty, wipe it with a cloth moistened with a small amount of neutral detergent. Wipe dry with a cloth.
- Volatile liquids such as alcohol, benzine, thinner, or insecticide will damage the surface finish.

# Please Read This

---

---

## Test Shooting

Before shooting, take a few test shots to make sure pictures are being taken normally.

---

## No Compensation for Picture Content

If a picture is not recorded due to a problem with the digital still camera, the recording content cannot be compensated.

---

## Copyright Laws

Pictures that you take with your digital still camera other than for personal enjoyment cannot be used without permission from the copyright owner in accordance with copyright laws. Be aware that even taking pictures of events like concerts, performances or exhibits for your personal enjoyment may be subject to the same copyright laws.

---

## About the Power Adaptor and Battery Pack

With this unit, use the AC adaptor/charger AC-VQ800 (supplied), or the “InfoLITHIUM” battery NP-F550 (not supplied). Other adaptors and batteries cannot be used. Be sure to charge the battery before using it for the first time.

---

## Connecting to the PC

This unit is equipped with a PC interface (IEEE1394) terminal that supports the DCCS (Digital Camera Command Set). You can use this terminal to connect the camera to your PC.

When connected to a PC, this unit cannot be used while other 1394 devices are connected. If this unit and any other IEEE1394 device are connected to a PC at the same time, the unit may not operate normally.

---

## “Memory Stick” and PC Card

To use a Sony “Memory Stick” MSA-8A (8 MB) with the digital still cameras, insert it into the Memory Stick/PC Card Adaptor MSAC-PC2.

The following PC cards may be used with the digital still camera:

- PC cards that conform to PC card standard 6.1
- Flash memory card ATA Type II
- PC cards with power specifications of 5V or 3.3 V/5 V.

3-volt products cannot be used. Using incompatible cards in the camera may result in breakdown.



---

## Camera Playback Data

- Picture data recorded by the camera may be played back on the camera
- Picture data that has been edited on a personal computer or processed may not be played back by the camera even if it is recorded by the camera.

---

## Data Recorded on the PC Card

Picture data is recorded in the following formats:


IMJP XXXX (folder name)/MVC XXXXX.jpg (file name)  
(When the mode menu quality settings are High, Middle, and Low.)

IMTIXXXX (folder name)/MVCXXXXX.tif (file name)  
(When the mode menu quality setting is Super.)

\* Picture is only indicated as XXXX/XXXXXX on the LCD monitor.

# Checking the Supplied Accessories


Before using the camera, make sure you have the following supplied accessories.




Lens cap (1, fitted on the camera)




Viewfinder cap (1, fitted on the camera)




Video cable (1)




Wireless remote control (1)




AC adaptor/charger AC-VQ800  
(with AC and DC power cables, 1)




Remote control cable (5 meters, 1)




User's manual (This book, 1)




PC interface cable (1)



TWAIN driver software on CD-ROM (1)



"Memory Stick" (1)



Memory Stick/PC Card Adaptor (1)

# Features

---

## 1/2 Inch 1,500,000 Pixel CCD

The digital still camera comes equipped with an all-pixel reading 1/2 inch CCD with 1,500,000 effective picture dots. The unit also uses a primary color filter and  $1344 \times 1024$  pixel high-resolution to reproduce the natural colors and resolution of photographs.

## 5× Wide Zoom Lens

To make the most of the high-resolution CCD, the camera is equipped with a 5× wide zoom lens for focal distances of 28 mm to 140 mm (equivalent to 35 mm film cameras). Use together with 2× digital zoom to reach the maximum of 10× zoom.

\* The resolution changes to  $640 \times 480$  pixels when using digital zoom.

## Two Finders: Viewfinder and Large LCD

The camera comes equipped with a viewfinder and a 2.5 inch low-temperature, polysilicon TFT color LCD with CRT contrast, resolution, and response speed.

## Precision Speed Auto Focus

With the auto focus function, you can automatically focus on subjects. By pressing the shutter button halfway, you can lock the focus at a fixed position and change the composition before taking the picture.

## Four Exposure Modes for Various Picture Taking Conditions

Light meter readings are first output from the CCD and then, depending on the picture taking conditions, one of four modes is chosen: Easy Program Exposure Mode for general picture-taking, Shutter Speed Priority Mode, Aperture Priority Mode and Manual Mode.

## Two Frames/Second High Speed Picture Taking with Buffer Memory Loading

Equipped with a continuous picture taking mode, the camera can take 2 frames per second of high-speed picture taking in  $640 \times 480$  size, low mode.

## Taking Pictures for a Longer Period with the “InfoLITHIUM” Battery and Power Saving Option

Using the “InfoLITHIUM” battery, it is possible to take pictures continuously for about two hours (with the LCD monitor off). Also, if the power is on and the camera is not operated for approximately 1 minute, power to the camera shuts off. If the camera is not operated for about 5 minutes, the whole unit shuts off (Auto Power Off function).

---

## Loading to a Video Output Terminal

If the unit is connected to a television by the supplied video cable, pictures taken by the digital still camera can easily be played back on the television. This can be a particularly powerful display tool for presentations for meetings and such.

---

## Using the PC Card and “Memory Stick”

The digital still camera uses the highly reliable PC card (PCMCIA ATA TYPE II) and long-lasting “Memory Stick” (for use when inserted in the Memory Stick/PC Card Adaptor) as the image recording medium.


---

## PC Interface (IEEE1394) Terminal

When the unit is connected to a PC using the supplied PC interface cable, images stored on the PC card can be digitally transferred to the PC, and the PC can be used to control the camera.

# Locations and Functions of Parts

## Front



### **1 Flash**

The camera has a built-in Guide Number GN10 flash. To use the flash, press the flash pop-up key. The cover will open and the flash warms up. The flash is stored when you close the cover.

### **2 Flash Pop-up Key**

Press the flash pop-up key to open the flash cover.

### **3 5× Zoom Lens**

You can manually adjust the zoom lens (28 mm to 140 mm (5×) on a 35 mm film camera) by rotating the zoom ring. After adjusting the zoom, manually adjust the focus with the focus ring.

### **4 White Balance Button**

When HOLD is set in the WB (white balance) mode, white balance can be adjusted by pressing this button.


### **5 Self-Timer Lamp**

When taking a picture with the self-timer, this lamp flashes when the release button is pressed. As the shutter release time draws near, the intervals between flashes become gradually shorter. The shutter is released when the light becomes constant.

### **6 Remote Control Signal Receiver**

Receives infrared signals transmitted by the wireless remote control.

## Rear



### **1 Viewfinder**

Lets you frame the picture.

### **2 Eyesight Adjustment Lever**

Adjusts the level of the viewfinder to suit the eyesight of the picture taker.

### **3 Review Button**

Lets you view and play back pictures during the time set in the REVIEW TIME of the custom menu when pressed directly after taking a picture.

### **4 AE-LOCK Button**

The exposure value is locked each time you press the AE lock button.

If the AE-LOCK button is pressed again or the release button is pressed, the lock function is cancelled the next time the camera is used.

### **5 Shift Dial**

Sets the picture quality and size (when the camera is in CAM mode) and changes the pictures that are played back (when the camera is in PLAY mode).

### **6 Neck Strap Belt Holder**

Where the neck strap belt is attached.

### **Caution**

Don't rotate the metal fittings on the holder.

**7 Access Lamp**

Lights in red when a card is accessed by the camera during picture taking or playback.

**Caution**

When the access lamp is lit, do not eject the card or turn off the power source. The PC Card or “Memory Stick” may be damaged.

**Note**

The PC Card and the “Memory Stick” installed in the Memory Stick/PC Card Adaptor are both referred to here as CARD.

**8 LCD Button**

Switches the LCD monitor on and off.

**9 INDEX/EZ.FOCUS button**

In the PLAY mode, pressing this button switches playback of captured images to Index. In the CAM mode, it switches to an enlargement of the image displayed on the LCD monitor.

**10 DISP (display) Button**

Turns LCD monitor information display on or off.

**11 LCD Monitor**

Lets you read necessary picture taking information, frame shots, and view recorded pictures.

**12 MENU Button**

Brings up the menu on the LCD monitor to change the settings of the camera or cards.

**13 EXECUTE Button**

Lets you choose items when adjusting settings in the menu.

**14 EXIT Button**

Returns you to the previous item or screen when changing settings in the menu.

**15 UP▲/DOWN▼ Button**

Selects menu items and changes values.



## **16 Power/Mode Dial**

Selects camera conditions when turned while the mode lock (green) is held down.

- OFF

Turns the power off.

- CAM

Allows you to take pictures (CAM mode).

- PLAY

Allows you to play back the pictures you have taken (PLAY mode).

- PC

Allows you to connect to the PC (PC mode).

### **Note**

#### **LCD Monitor Display**

When the power/mode dial is turned to CAM, the LCD monitor remains off. If necessary, press the LCD button to turn the LCD monitor on.

When the power/mode dial is turned to PLAY, the LCD monitor automatically turns on.

## **17 Card Cover Lock**

Slide this lock to enable card insertion or ejection.


## **18 Card Eject Button**

Press this button to eject cards.

## **19 Card Cover**

Open or close this cover to set the card in place or to eject it.

## Top

**1 Focus Ring**

Rotate left or right to adjust the focus.

**2 Zoom Ring**

Rotate left or right to adjust the zoom ratio of the zoom lens.

**3 Release Button**

Operates the shutter when shooting.

**4 [●] (Light Metering Select) Button**

By turning the shift dial while pressing this button, you can choose from Spot (○ Spot light metering) or Average ([ ]: average light metering) to measure the light needed for proper exposure.

**5 [EV] (EV) Button**

By turning the shift dial while pressing this button, you can correct the exposure when taking pictures.

**6 LCD Panel**

Picture taking settings, such as shutter speed and aperture, are displayed on the LCD panel.

**7 Accessory Shoe**

Attach external flashes here.

**8 Focus Mode Switch**

Switches the focus mode between auto and manual.

### **[9] Mode Dial**

Pressing the shift button (top button) after it has been adjusted to the desired position sets the picture size and quality (in CAM mode) and changes the picture to be played back (in PLAY mode).

### **[10] Shift Button**

Pressing this button after moving the mode dial to the desired position sets the picture quality or picture size (in CAM mode) or changes the picture that is played back (in PLAY mode).

### **[11] Connector Cover**

When using the video output terminal, the i.LINK terminal, or the remote control terminal, open this cover to connect the video cable.

### **[12] Connector Cover Lock**

Slide this lock to open the connector cover.

### **[13] Video Output Terminal**

To view pictures on a television, connect the video cable (supplied) to this terminal.


### **[14] PC interface Terminal (6-Pin, 400 Mbps)**

When operating the camera from a PC, connect the PC interface cable (supplied) here to view pictures on the PC.

### **[15] Remote Control Terminal**

To use the remote control RM-S7D (supplied), connect it here using the remote control cable (supplied).

## Bottom



### **1 Tripod Hoke**

Attach a tripod here. Standards are as listed below.

ISO Standard  $l = 4.5\text{mm} \pm 0.2\text{mm}$

ASA Standard  $l = 0.197 \text{ inch}$

### **2 Battery Cover**


Open or close this cover to insert or take out the battery pack.

### **3 Battery Cover Lock**

Slide this lock to insert or take out the battery pack.

# LCD Panel


## CAM Mode/PC Mode



### Note


In CAM mode/PC mode, when the release button is pressed while pressing the shift button, the shutter speed indicator changes to the remaining shot number indicator and the aperture indicator changes to remaining shooting time. Because remaining shooting time is displayed as only two digits, any time over 99 minutes is displayed as 99. The viewfinder display changes in the same way.

## PLAY Mode



## LCD Monitor

### CAM Mode/PC Mode




\*1 The illustration above shows the monitor in CAM mode. When the monitor is in PC mode, "PC" appears here.

\*2 The illustration above shows the monitor AE frame. You can also choose from Guide90 or Guide0 frame (page 75).

\*3 Remaining shooting time is not displayed when using the AC power adaptor/charger AC-VQ800. Ordinarily, remaining shooting time is displayed, then the battery indicator illuminates when the battery runs low.


### PLAY Mode



\* Ordinarily, remaining playback time is displayed. Then the battery indicator illuminates when the battery runs low.

The remaining playback time is not displayed when using AC power adaptor/charger AC-VQ800.

# Viewfinder



\* The EV compensation is displayed when EV Button is pressed.

# Preparations

## Charging the Battery Pack

Charge the battery pack NP-F550 (not supplied) using AC power adaptor/charger AC-VQ800 (supplied).

Be sure to charge the battery pack before using it for the first time.

Charge the battery pack when necessary, as indicated by the remaining shooting time on the LCD monitor or the battery indicator on the LCD panel.

### Battery Pack Charging Time

When it is time to charge the battery, the battery indicator on the LCD panel flashes. For further reference see “Warning Indicators” (page 116).

### Battery Pack Charging Time

Battery Charger	Charging time for practical use*	Time for full charge
AC-VQ800	Approx. 55 minutes	Approx. 115 minutes


\* The time needed for charging an empty NP-F550 battery pack.

### Continuous Use with the Battery Pack

The usage time with a fully charged battery:


Battery Pack	Shooting time*		Playback time	
	LCD monitor off	LCD monitor on	LCD monitor off	LCD monitor on
NP-F550	Approx. 2.5 hours	Approx. 1.5 hours	Approx. 5 hours	Approx. 2.5 hours

\* Times shown are standard values for continuous general photography at 20°C (68°F) with the flash off. The time is reduced by repeatedly turning the power on and off.



- 1 Slide the AC adaptor/charger’s mode switch to the charge position.
- 2 Connect the AC power cable to the AC adaptor/charger.
- 3 Plug the AC plug of the AC power cable into a wall socket.





- 4 Set the battery pack into its receptacle on the AC adaptor/charger as shown, making sure that the ▲ mark is adjacent to the notch on the lift (the L series side).

- 5 Pushing the battery pack down (a), slide it all the way to the left (b).  
  
When charging starts, the battery marks in the display window light in succession and the charge lamp lights. When the battery is charged, all of the battery marks light (practical use charge). Further, if you continue charging until the charge lamp goes out and the battery mark shows FULL, you can use the battery for a little longer than normal (full charge).

- 6 After charging has finished, slide the battery pack fully to the right and remove it from the AC adaptor/charger.

### This camera operates only with the “InfoLITHIUM” battery (L series).


The “InfoLITHIUM” battery is a new type of lithium ion battery which can exchange data with compatible video equipment about its battery consumption. The digital still camera supports the “InfoLITHIUM” battery (L series). The “InfoLITHIUM” battery is recognized by the

 InfoLITHIUM  mark.


“InfoLITHIUM” is a trademark of Sony Corporation.

## Installation of the Battery Pack


After charging the battery, install it in the camera.



- 1 Make sure the camera power/mode dial is set to the OFF position.




- 2 Slide the battery cover lock in the direction of the ▲ mark (a), and open the battery cover (b).



- 3 Insert the battery ▲ mark side first until it firmly locks in place.

- 4 Close the battery cover.




## Removing the Battery

- 1 Make sure the camera power/mode dial is set to the OFF position.
- 2 Slide the battery cover lock in the direction of the ▲ mark and open the battery cover.
- 3 Rotate the battery cover lock to the outside and remove the battery pack.

## Setting the Time and Date

The shooting time and date are recorded automatically with information from the camera's internal clock. Set the clock to ensure the correct time and date are recorded.



**1** While pressing the mode lock (green), turn the power/mode dial to CAM mode.

**2** Press the MENU button.  
The LCD monitor turns on and the menu is displayed.

**3** Press the ▲(UP)/▼(DOWN) buttons to select "Date & Time".

```
CAMERA MENU
Custom
PC Card INIT
User File Save
New Folder
ID Set
File No. Mem
WB Flash
Date & Time
LCD Set
Display Set
```

**4** Press the EXECUTE button.  
The DATE & TIME menu is displayed.

**5** Select "Set" using the ▲(UP)/▼(DOWN) buttons and then press the EXECUTE button.

The year can now be set.

```
DATE & TIME

Set      1999-07-04 20:45:58
Date Form  yyyy-mm-dd
```

- 
- 6** Set the year using the ▲(UP)/▼(DOWN) buttons and then press the EXECUTE button.

The month can now be set.

- 
- 7** Set the month, day, hour, minutes and seconds in the same way as explained in step 5.

- 
- 8** Select “Date Form” using the ▲(UP)/▼(DOWN) buttons and then press the EXECUTE button.

You can now select the date display format.

- 
- 9** Select the date display format using the ▲(UP)/▼(DOWN) buttons and then press the EXECUTE button.

You can choose from the following 3 date display formats. [yyyy] indicates year, [mm] indicates month and [dd] indicates day.

yyyy-mm-dd (ex:1999-07-04)

dd-mm-yyyy (ex:04-07-1999)


mm-dd-yyyy (ex:07-04-1999)

- 
- 10** Press the EXIT button.

The time and date are set and the menu returns on the LCD monitor.

- 
- 11** Press the EXIT button.

The menu disappears from the monitor.



## Keeping correct time

A separate lithium button battery is used by the camera to power the internal clock. When turning the power dial to CAM or PLAY from OFF, if the message “Date & Time not set” appears, it is time to charge the lithium button battery.


Inquire about charging the battery at the store where you bought the camera or at any Sony service center.

## Preparing the Card

The picture is saved on the PC Card inserted in the camera (not supplied) or on the “Memory Stick”. Insert the “Memory Stick” in the Memory Stick/PC Card Adaptor and then insert the adaptor into the camera.


In this guide the “Memory Stick”, when inserted in the Memory Stick/PC Card Adaptor, and the PC Card are referred to as Card.

### Inserting the “Memory Stick” in the Memory Stick/PC Card Adaptor




- 1** Making sure the side of the “Memory Stick” with the ▲ mark is facing up, insert it into the Memory Stick/PC Card Adaptor until it is locked firmly in place.

### To Take out the “Memory Stick” from the Memory Stick/PC Card Adaptor




- 1** Push the EJECT button on the Memory Stick/PC Card Adaptor.
- 2** Pull out the “Memory Stick”.

## Inserting the Card




- 1 Slide the card cover bar lock downward (a) and open the card cover (b).



- 2 Insert the card in the camera.


### Caution

Make sure to insert the card in the proper direction. Forcing the card may result in damage to the camera and/or the card. If you insert a card that has never been initialized, **FORMAT ERROR** flashes on the LCD monitor. Initialize the card. (Page 31)



- 3 Close the card cover.

## To Remove the Card




- 1 Open the card cover.
- 2 Push the card eject button.
- 3 Pull out the card.

## Initializing a Card

Uninitialized PC cards cannot be used in the camera. Before use, cards must first be initialized using the camera.

### Caution

**If you initialize a card that has data recorded on it, all recorded data, including protected picture data, will be erased.**



- 1 While pressing the mode lock (green), turn the power/mode dial to CAM mode.

### Note

Initializing PC cards is explained here with the power source/mode dial set to CAM mode, but the same operation can be performed in PLAY mode.

- 2 Press the MENU button.

The LCD monitor turns on and the menu is displayed.

- 3 Select "PC Card INIT" using the ▲(UP)/▼(DOWN) buttons and then press the EXECUTE button.



The message "Initialize OK?" appears.

- 4 Press the EXECUTE button.

Initialization begins.


When initialization is complete, the LCD monitor returns to the normal display (as shown in step 1).

#### Caution

**Do not take out the card during initialization. Initialization cannot proceed normally.**

## Attaching the Viewfinder Cap

Place the cap on the viewfinder when taking pictures with the LCD monitor under strong sunlight, such as outdoors. Keeping the cap on the viewfinder prevents strong rays of light from affecting the recorded pictures.






# Taking a Picture

## Taking Pictures


Taking pictures is easy with automatic focus.

In this manual, taking pictures while looking through the viewfinder is explained, but you can take pictures while looking through either the viewfinder or the LCD monitor.




**1** Take off the lens cap.

**2** While pressing down the mode lock (green), turn the power/mode dial to CAM mode.  
The indicators in the viewfinder turn on.



**3** Turn the eyesight adjustment lever to where you can clearly see the circle in the center of the viewfinder.




**4** If there is insufficient light to shoot the subject (shutter speed or F-stop flashes), press the flash pop-up key to open the flash.

In conditions where it is necessary to use the flash, the flash indicator blinks, and flash preparation begins.

The flash indicator lights when the flash is ready for use.

**5** Set the focus mode switch to AF.




- 6 Center the subject on which you'd like to focus in the center of the finder.



- 7 Adjust the zoom by rotating the zoom ring left or right.

- 8 Press the release button halfway.

The AF LOCK indicator in the viewfinder flashes. When the subject is focused, the indicator stays lit and a beep sounds. (This setting can be changed so that the beep does not sound.)




- 9 Press the release button completely.

When the access lamp lights, the picture is being recorded on the card.

When the access lamp goes out, recording on the card is completed and the camera is ready to take the next picture.

### Caution

**When the access lamp is lit, do not remove the card or turn off the power. You may damage the PC Card or "Memory Stick".**



- 10** Turning the power/mode dial to OFF turns the power off.

**Note**

If you do not operate the camera for about one minute when the camera is on in the CAM mode, the LCD monitor automatically shuts off (Standby Mode).

Also, if the camera is not touched for approximately four minutes after that, the camera automatically shuts completely off.


## Auto Focus

This camera employs an auto focus mechanism. When auto focus is turned on, the camera automatically focuses on the picture subject. Auto focus is turned on by setting the focus mode switch to AF. Centering the LCD monitor or the center of the finder on the subject and pressing the release button halfway focuses the picture frame.


When taking pictures with auto focus ON, check the AF focusing mark in the LCD monitor or viewfinder and listen for the beep. (This setting can be changed so that the beep does not sound.) If you press the release button halfway, the AF focusing mark changes as follows:

### • On the LCD monitor

When the release button is pressed halfway, the AF focusing mark flashes green.




When the picture is focused, the indicator lights a steady green. If the picture cannot be focused, the indicator lights a steady red.




### • In the viewfinder


When the release button is pressed halfway, the AF focusing mark flashes.



When the picture is focused, the indicator lights steadily.




When the picture cannot be focused, the indicator continues flashing.



## Locking the Focus

When you focus the picture by pressing the release button halfway, the focus is set at that distance until you release the button. This is called Focus Lock. If you want to take a picture of a subject on the edge of the picture composition, engaging Focus Lock allows you to move the camera and then take the picture.



- 1 Center the subject in the viewfinder and press the release button halfway.

The focus is fixed.



- 2 Move the camera to frame the composition you want.



- 3 Press the release button down completely.

### Note

#### AE-LOCK

When you press the release button halfway to set the focus, the exposure value is also set. This is indicated by the AE-LOCK indicator  $\times$  in the viewfinder and by highlighted display of the exposure value and shutter speed on the LCD monitor.


Also, if you frame a subject that you'd like to manually set the exposure for and press the AE-LOCK button, the exposure for that subject is fixed.

Use this function when it is necessary to change the picture composition after deciding the exposure. This is effective for picture taking under such conditions as where there is backlight. To cancel AE-Lock, press the AE-LOCK button again, or press any other operation button.

## Setting the Focus Manually

You can set the focus manually with this camera.

There are situations in which it is better to set the focus manually than use the auto focus function.



**1** Set the auto focus mode switch to MF.

**2** Adjust the focus by turning the focus ring left or right.

### Notes

- The focus ring can be rotated completely in either direction.
- Set the focus after adjusting the zoom. If you set the appropriate zoom distance first, you can get a more accurate focus.
- The picture displayed on the LCD monitor can be temporarily enlarged to double size by pressing the INDEX/EZ.FOCUS button. By focusing the picture in this enlarged state, you can get a better focus for shooting the picture. Press the release button halfway to return to the original image size. When [x2 D.Zoom] is selected for the picture size, the picture displayed on the LCD monitor cannot be enlarged even if the INDEX/EZ.FOCUS button is pressed.

## Situations in which auto focus may not work well

- When there is a very bright object near the subject;
- When the subject is near a highly reflected surface such as mirrors or polished metals;
- For subjects with non-reflective surfaces such as a black sweater;
- On subjects with small surface areas such as wire netting or lattices;
- On subjects with ephemeral shapes, such as smoke, flames or fireworks;
- On subjects with extremely low contrast;
- On subjects without vertical lines such as Venetian blinds;
- When the subject is moving fast.

---

## Situations in which it is better to focus manually

- When the subject and its surroundings are both dark;
- When the subject offers little contrast on the screen, such as with walls or the sky;
- When the background is too bright or the contrast between the background and the subject is too great;
- When the subject has a fine, repeating pattern such as stripes;
- When the subject is behind a window that is dirty or wet;
- When there is a wire fence in front of the subject;
- When the subject is bright, emits or reflects light;
- When you want to take pictures of still subjects with a tripod.

# Viewing

## Checking the Picture Content

Below are the different ways for playing back recorded pictures.

- **Viewing pictures in succession**

Pictures are played back one by one in sequence.


- **Viewing pictures in an automatic cycle**

Pictures are automatically played back in a cycle.

- **Viewing the picture index**

Pictures are displayed all at once. This is a convenient way to search for a specific picture.

## Viewing Pictures in Succession



1

While pressing the mode lock (green), turn the power/mode dial to PLAY.

The access lamp lights and the camera reads the last picture taken.

When the access lamp goes out, reading is finished, and the picture is played back.



2

Rotate the shift dial to change the picture.


Turning the wheel right plays back the next picture; turning the wheel left plays back the previous picture.

### Note

While pressing down the shift button, turn the shift dial to choose which picture to play back. When you release the shift button, the picture you have chosen plays back immediately. (Picture Search).



In Picture Search, when you rotate the shift dial while holding down both the shift button and the release button, you can skip 50 pictures at a time.




- 3** Turn the power/mode dial to OFF to turn off the power.

#### Note

If the camera is on but not operated for about three minutes, power to the LCD monitor shuts off (Standby Mode). Also, if the camera is not operated for approximately another two minutes, the camera shuts off completely. In Standby Mode you can return to the playback condition by touching any button, dial or switch on the camera. When the camera has shut itself completely off, you can return to the playback condition by pressing the release button.

## Viewing Pictures in an Automatic Cycle

Pictures are automatically played back frame by frame.



- 1** While pressing the mode lock (green), rotate the power/mode dial to PLAY.

The access lamp lights as the camera reads the last picture taken.

Reading is finished when the access lamp goes out. The picture is played back.

- 2** Press the MENU button.  
The menu is displayed on the LCD monitor.

- 3** Select "Auto Play" using the ▲(UP)/▼(DOWN) buttons and then press EXECUTE.


```
PLAY MENU
Rotate
D.Zoom
Auto Play
Protect
Delete
PC Card INIT
ID Set
LCD Set
Display Set
```

The Auto Play menu is displayed.



- 
- 4** Select “Interval Time” using the ▲(UP)/▼(DOWN) buttons and then press EXECUTE.

You can now set the number of seconds to display one picture.



- 
- 5** Select the display interval time using the ▲(UP)/▼(DOWN) buttons and then press the EXECUTE button.

**Note**

You can set the interval time between the range of 1 to 30 seconds (in 1 second units). However, depending on the playback quality and size, the set time might be overridden.

- 
- 6** Select “Start” using the ▲(UP)/▼(DOWN) buttons and then press EXECUTE.

The pictures are automatically cycled for the period of time you set.

When all the recorded pictures have been played back, playback is repeated from the first picture.


- 
- 7** To pause playback, press the EXECUTE button.

Playback momentarily stops. To cancel the pause function, press the EXECUTE button again.

**Note**

When you press EXIT while in pause, playback stops in mid-sequence and the LCD monitor returns to the Auto Play menu.

To restart playback, press the EXECUTE button again.



- 8** To end automatic playback, press the release button halfway.


Automatic playback ends and the image appearing when you pressed the release button is displayed.

- 9** Turn the power/mode dial to OFF to turn the camera off.

### Note

When the camera is set to automatic playback, the Auto Power Off function does not work.

## Viewing the Picture Index




- 1** While pressing the mode lock (green), turn the power/mode dial to **PLAY**.

The access lamp lights and the camera reads the last recorded picture.

Reading is finished when the access lamp goes out, and the picture is played back.


- 2** Press the **INDEX/EZ.FOCUS** button.

The LCD monitor display switches to index view.



### 3 Rotate the shift dial to select a picture.

The color of the picture you have chosen changes and information about that picture, such as date and exposure, is displayed.




#### Note

In Index Mode, when you rotate the shift dial while holding down the shift button, you can jump ten frames to choose a picture.

When you rotate the shift dial while holding down the shift button and the release button simultaneously, you can jump 50 frames to choose a picture.

### 4 To close index view, press the INDEX/EZ.FOCUS button again.

The pictures that you selected are played back one at a time.




### 5 Turn the power/mode dial to OFF to turn the power off.

#### Note

If the camera is on but not operated for about three minutes, the LCD monitor shuts off (Standby Mode). Also, if the camera is not operated for approximately another two minutes, the camera shuts off completely. In Standby Mode you can return to the playback condition by touching any button, dial or switch on the camera. When the camera has shut itself completely off, you can return to the playback condition by pressing the release button.

## Viewing Pictures on a Television

You can view pictures taken with the digital still camera on a television when it is connected to the TV's video terminal. This is convenient for adjusting the focus and viewing pictures in succession.



- 1 Use the video cable (supplied) to connect the camera video output terminal to the television video terminal.

### Note

**It is not possible to connect to a television that only has an antenna input terminal.**

- 2 Set the television TV/video switch to VIDEO.
- 3 Play back the pictures through the camera.

### Note

You can turn the LCD monitor display off by pressing the LCD button.

## Using a PC Card Reader

When you connect a PC card reader on your computer and install the driver, the card is recognized as a drive. In this way, you can manage pictures saved on the card as computer files.

For further details on the PC card reader or driver, please refer to the PC card reader user's manual. For further details about managing pictures on your computer, please see the user's manual for the picture processing application or the application's help function.

## Using the PC Card/Parallel Port Adaptor

When you connect the MSAC-PR1 PC card/parallel port adaptor on your computer and install the MSAC-PR1 device driver, the card is recognized as a drive. In this way, you can manage pictures saved on the card as computer files.

The methods of connecting the PC card/parallel port adaptor to the computer and installing the PC card/parallel port adaptor driver are explained in this guide.

For further details about managing pictures on your computer, please see the user's manual for the picture processing application or the application's help function.


### Connecting the PC Card/Parallel Port Adaptor

The PC card/parallel port adaptor connects to the parallel port connection terminal used by the computer keyboard.

Be sure the computer is turned off when you connect the adaptor.

#### Note

**The PC card/parallel port adaptor uses energy supplied by the computer keyboard connection terminal. In some cases, insufficient energy is supplied by laptop computers. In such cases, use the PC card slot on your laptop computer.**



- Of the 2 DIN terminals, connect to the one that serves as the computer keyboard connection terminal.
- Between the camera and the keyboard, adjust the size of the DIN connector of the keyboard and the power cable using a converter connector.
- There is no need to connect to the keyboard with laptop computers.
- If a printer will not be used, there is no need to connect the printer cable.

## Installing the Driver

- 1 Insert the supplied CD-ROM into the CD-ROM drive.  
The “Sony MSAC-PR1 Setup” dialog box appears.
- 2 Click “Install Sony MSAC-PR1 Drivers”.  
The “Setup Language” dialog box appears.



- 3 Select a language and click [Next].  
The “Welcome” dialog box appears.



---


**4** Click [Next].

The “Software License Agreement” dialog box appears.

---

**5** After reading and agreeing with the terms of the Software License Agreement, Click [Yes].


The “Choose Destination Location” dialog box appears.



---


**6** Specify a destination folder for installation and click [Next].

The “Select Program Folder” dialog box appears.



## 7 Specify a program folder name and click [Next].

The “Start Copying Files” dialog box appears.



## 8 Confirm the displayed installation settings and click [Next].


Installation starts and the “Sony MSAC-PR1 Drive Identification” dialog box appears.





- 9** Confirm the drive name of the PC card/parallel port adaptor and click [OK].

The “Setup Complete” dialog box appears.



- 10** Click [Finish].


In step 9, if the “Yes, I want to read the README file now” box is checked, the README document is displayed. Installation is complete.

## Inserting the Card

When you insert the card into the PC Card/Parallel port Adaptor, the drive that was specified as the drive name in step 8 of the “Install Driver” directions (page 49) is recognized. You can now manage the card contents on your computer.

### Note

**When using the “Memory Stick”, insert the “Memory Stick” into the Memory Stick/PC Card Adaptor.**



- 1** Make sure the power/access lamp is not flashing.


### Caution

**If you insert the card when the power/access lamp is flashing, you may damage the PC Card or “Memory Stick”.**

- 2** Make sure the ▲ mark is facing up and slowly slide the card into the card insertion slot.

---

## Taking Out the Card



- 
- 1 Make sure the power/access lamp is not flashing.

**Caution**

**Do not take out the card when the power/access lamp is flashing. Doing so may result in damage to your PC Card or "Memory Stick".**

- 
- 2 Press the eject button and slowly pull out the card.

---

## Uninstalling the Driver

If the MSAC-PR1 device driver is no longer necessary, you may remove it from your computer using the steps below.

- 
- 1 Click [Start] in the task bar, and then open [Program] from the [Start] menu and click on [Sony MSAC-PR1]-[Uninstall].


The uninstall confirmation dialog box is displayed.

- 
- 2 Click [Yes].  
The uninstall program starts. The dialog box "Remove Programs From Your Computer" is displayed and file erasure begins.

- 
- 3 When uninstallation is complete, click [OK].

## Choosing the Exposure Mode

Choose the exposure mode from the choices Program AE (Program), Aperture Priority AE (Aperture), Shutter Speed Priority AE (Shutter) or Manual Exposure (Manual).



**1** While pressing the mode lock (green), turn the power/mode dial to CAM.

**2** Press the LCD button to turn the LCD monitor ON.


### Note

Settings can also be confirmed on the LCD panel. When checking the settings on the LCD panel, this step is not necessary.

**3** Turn the mode dial to AE and press the shift button.

The exposure mode menu is displayed.

**4** While pressing the shift button, rotate the shift dial to choose a exposure mode.



### Program (Program AE)

In this mode, the aperture and shutter speed are both changed simultaneously according to the brightness of the subject. The correct exposure is automatically chosen.

### Aperture (Aperture Priority AE)

When the aperture is fixed, the shutter speed is automatically changed according to the brightness of the subject to obtain the correct exposure.

## Shutter (Shutter Speed Priority AE)

When the shutter speed is fixed, the aperture is automatically changed according to the brightness of the subject to obtain the correct exposure.

## Manual (Manual Exposure)

You can decide the exposure by setting the shutter speed and aperture manually.

### Note

Exposure modes are indicated on the LCD panel as P (Program AE), A (Aperture priority AE), S (Shutter Speed priority AE), and M (Manual Exposure).

## 5

Release the shift button.

When the exposure mode is set, exit the menu.  
The camera is ready to take pictures.

### Note

After deciding the exposure mode, select the shutter speed and/or aperture as explained below.

## Program AE

Turn the shift dial to choose a fixed shutter speed and aperture combination.

## Aperture Priority AE

Turn the shift dial to the desired aperture.

## Shutter Speed Priority AE

Turn the shift dial to the desired shutter speed.

## Manual Exposure


Turn the shift dial to choose the shutter speed.

While pressing the  button, turn the shift dial to choose the aperture.

When a picture is taken at low shutter speed, white dots may appear on the screen. This does not indicate that the camera is malfunctioning.

## Choosing Picture Size

Choose the picture size to be recorded during shooting from among the following: 1344 × 1024, 640 × 480, ×2D. Zoom. The larger the size, the fewer the number of pictures that can be recorded.



**1** While pressing the mode lock (green), turn the power/mode dial to CAM.

**2** Press the LCD button to turn the LCD monitor ON.


### Note

Settings can also be confirmed on the LCD panel. When checking the settings on the LCD panel, this step is not necessary.

**3** Turn the mode dial to SIZE and press the shift button.

The PICTURE SIZE menu is displayed.

**4** While pressing the shift button, rotate the shift dial to choose a picture size.



### 1344 x 1024

Records pictures in 1344 × 1024 pixel format.

### 640 x 480

Records pictures in 640 × 480 pixel format.

### ×2 D. Zoom

The mode for shooting pictures at 2× the virtual focal distance (about 56 to 280mm for 35mm film cameras). Pictures shot with ×2D. Zoom are recorded in 640 × 480 pixel format.

Because the picture frame narrows in this mode, check shots with the LCD monitor. You cannot check the true picture frame in the viewfinder.

### Note

Picture size settings are indicated on the LCD panel as 1344 (1344 × 1024), 640 640 (640 × 480), and x2 (×2 D. Zoom).


5

Release the shift button.

When the picture size is set, exit the menu. The camera is ready to take pictures.

## Choosing the Picture Quality Mode

Choose the picture quality of shots recorded during shooting. You can choose from Super, High, Middle and Low. The number of pictures you can take differs depending on the picture quality.



1

While pressing the mode lock (green) turn the power/mode dial to CAM.

2

Press the LCD button to turn on the LCD monitor.

### Note


Settings can also be confirmed on the LCD panel. When checking the settings on the LCD panel, this step is not necessary.

3

Turn the mode dial to QLTY and press the shift button.

The QUALITY menu appears.

- 4
- Rotate the shift dial while pressing the shift button. Choose a picture quality mode.



Picture Size	Super	High	Middle	Low
1344 × 1024	Non compression	Approx.1/4	Approx.1/8	Approx.1/16
640 × 480 ×2D. Zoom	Non compression	Approx.1/3	Approx.1/6	Approx.1/12
	TIFF RGB picture	JPEG Y-C compressed picture		

- Super**  
Select this to get the highest quality picture.
- High**  
Select this when you want to give your picture quality priority over the number of pictures.
- Middle**  
Select this to shoot with average picture quality.
- Low**  
Select this to give the number of pictures priority over the picture quality.



Note

Picture quality is indicated on the LCD panel as S (Super), H (High), M (Middle), and L (Low). Except for “S” mode, the picture data is compressed, which will result in a loss of quality.

- 5
- Release the shift button.
- When the picture quality mode is set, exit the menu. The camera is ready to take pictures.

## Choosing the Picture Taking Brightness (EV compensation)

When a exposure mode other than manual exposure (Manual) is chosen, you can adjust the brightness to fit the shooting conditions.




**1** While pressing the mode lock (green), turn the power/mode dial to CAM.

**2** Press the LCD button to turn on the LCD monitor.

### Note

Settings can also be confirmed on the LCD panel. When checking the settings on the LCD panel, this step is not necessary.

**3** Rotate the shift dial while pressing the EV button to adjust the brightness.



Brightness correction (EV compensation)

You can tune within the range from -2.0 EV to +2.0 EV (in 0.25 EV units).

**4** Release the EV button.  
The brightness correction is set.



## Adjusting for Natural Color Tone (White Balance Adjustment)


This camera comes equipped with the white balance function to give a more natural color tone to your pictures in a variety of shooting conditions.

Choose a white balance mode from Auto White Balance (Auto), White Balance Hold (Hold), Outdoor (Outdoor), and Indoor (Indoor). With White Balance Hold you can adjust the most appropriate white balance for the shooting condition.

### Note

White balance is the balance of the level of white among the channels of R (red), G (green), and B (Blue) in a digital camera. If a picture is taken with this balance properly adjusted, reds or blues do not overwhelm the composition and a white subject is shot with appropriate level of white.

## Choosing the White Balance Mode




- 1** While pressing the mode lock (green), turn the power mode/dial to CAM.
- 2** Press the LCD button to turn on the LCD monitor.
 

**Note**  
 Settings can also be confirmed on the LCD panel. When checking the settings on the LCD panel, this step is not necessary.

- 3** Turn the mode dial to WB and press the shift button.  
The WB MODE menu appears.

- 4** While pressing the shift button, rotate the shift dial to choose the white balance mode.



## Auto (Auto White Balance)

This is the default. White balance is automatically adjusted to give a natural color tone according to the amount of light when shooting.

## Hold (White Balance Hold)

Choose this when you want better color reproduction or you are shooting a monochrome subject and background. Press the WB button to adjust the white balance. For further information refer to the Adjusting the White Balance Hold section below.

## Outdoor (Outdoor)

White balance is automatically adjusted to attain natural colors when shooting outdoors.

## Indoor (Indoor)

White balance is automatically adjusted to attain natural colors when shooting indoors.

### Note


White balance modes are indicated as ATW (Auto), WB/HOLD (Hold), [☀] (Outdoor), and [🏠] (Indoor) on the LCD panel.

5

Release the shift button.

After the white balance mode is set, exit the menu. The camera is ready to take pictures.

## Adjusting White Balance with White Balance Hold



1

Choose WHITE BALANCE HOLD as the white balance mode.

2

Point the camera at a completely white subject until it fills the viewfinder.

3

Push the WB button.

WB is indicated in the viewfinder and the white balance adjustment begins.

When the WB indicator disappears, white balance adjustment is complete.

The camera is ready to take pictures.

The white balance you have chosen is valid until you readjust it.


### Note

**When the WB indicator flashes, the white level was not successfully adjusted.**

**Press any other operation button to leave this mode, then begin the white balance adjustment process again.**

## Changing the ISO Sensitivity

You can get the same effect with this mode as is achieved by using films with different ISO sensitivities in film cameras. You can choose from ISO 50, 100 and 400.



- 1 While pressing the mode lock (green), turn the power/mode dial to CAM mode.

- 2 Push the LCD button to turn on the LCD monitor.


### Note

Settings can also be confirmed on the LCD panel. When checking the settings on the LCD panel, this step is not necessary.

- 3 Turn the mode dial to ISO and then press the shift button.

The ISO MODE menu appears.

- 4 Rotate the shift dial while pressing the shift button. Choose an ISO sensitivity.



## 50

Sets sensitivity equal to ISO 50. Use this sensitivity when there is sufficient light, such as in the bright outdoors, for a finer image than with ISO 100.

## 100

Sets sensitivity equal to ISO 100. This is the standard ISO sensitivity.

## 400

Sets sensitivity equal to ISO 400. Use this sensitivity when you want to shoot a picture in a room without using a strobelight, or when there is not enough sunlight. The picture quality with this sensitivity is not as good as with ISO 100.


## 5

Release the shift button.

After the ISO sensitivity is set, exit the menu. The camera is ready to take pictures.

## Choosing a Light Metering Method

According to the picture taking conditions and purpose, you can choose the method for measuring light for the exposure from AVERAGE ([ ]) or SPOT (○).



## 1


While pressing the mode lock (green), turn the power/mode dial to CAM.

## 2


Press the LCD button to turn the LCD monitor on.

### Note

Settings can also be confirmed on the LCD panel. When checking the settings on the LCD panel, this step is not necessary.



- 3 While pressing the [●] button (SPOT light meter switch button), turn the shift dial to choose the light meter reading method.



### AVERAGE (Center-weighted average light metering)

Appropriate for average picture taking conditions. Takes the average light metering of the whole screen after you have placed the focal point in the center of the viewfinder.

### SPOT (Spot Light Metering)

Takes the light metering of a small range located in the central part of the viewfinder. This is effective for taking pictures of subjects surrounded by a lot of light, or that is backlit.

#### Note


Light metering options are indicated in the finderview as [ ] (AVERAGE) and ○ (SPOT).

- 4 Release the [●] button.  
After the light metering has been set, the camera is ready to take pictures.

## Resetting the Content of the Setting

Resetting the modes returns the following settings to those set forth by the factory.

- mode dial settings
- Miscellaneous Settings (page 73)



**1** While pressing the mode lock (green), turn the power/mode dial to CAM mode.

**2** Press the LCD button to turn on the LCD monitor.

### Note

Settings can also be confirmed on the LCD panel. When checking the settings on the LCD panel, this step is not necessary.

**3** Turn the mode dial to USER and then press the shift button.

The USER FILE menu appears.

**4** While pressing the shift button, turn the shift dial to choose NO. 0 (reset).

CAM	
USER FILE	
-----	-----
No. 0	(reset)
No. 1	1999-07-04
No. 2	1999-07-04
No. 3	1999-07-04


**5** Release the shift button.

When the settings are reset, exit the menu. The camera is ready to take pictures.

## Saving the Content of Settings

You can save the content of the following settings in up to 3 user files.

- mode dial settings
- the content of Miscellaneous Settings (page 73)



**1** While pressing the mode lock (green), turn the power/mode dial to CAM mode.

**2** Press the MENU button.  
The LCD monitor turns on and the menu is displayed.

**3** Choose "User File Save" using the ▲(UP)/▼(DOWN) buttons.


```
CAMERA MENU
Custom
PC Card INIT
User File Save
New Folder
ID Set
File No. Mem
WB Flash
Date & Time
LCD Set
Display Set
```

**4** Press the EXECUTE button.  
The USER FILE SAVE menu appears.

**5** Using the ▲(UP)/▼(DOWN) buttons, choose a user file number from No. 1 to No. 3.

```
USER FILE SAVE

No.1(User1) 1999-07-04
No.2(User2) 1999-07-04
No.3(User3) 1999-07-04
```



- 6 Press the EXECUTE button.

The setting content is saved as a user file with the chosen file number. The date and time the file is saved is also displayed.

- 7 Press the EXIT button.


The LCD monitor display returns to the menu.

- 8 Press the EXIT button.

After exiting the menu, the camera is ready to take pictures.

## Reading the Saved Settings

Reading the user file you have saved sets the same content in the user file.



- 1 While pressing the mode lock (green), turn the power/mode dial to CAM mode.

- 2 Press the LCD button to turn the LCD monitor on.

### Note

Settings can also be confirmed on the LCD panel. When checking the settings on the LCD panel, this step is not necessary.

- 3 Turn the mode dial to USER and press the shift button.

The USER FILE menu appears.




- 4 While pressing the shift button, turn the shift dial to choose a user file number from No. 1 to No. 3.

CAM	
USER FILE	
No. 0	(reset)
No. 1	1999-07-04
No. 2	1999-07-04
No. 3	1999-07-04

- 5 Release the shift button.  
The content of the selected user file number is changed, and the camera is ready to take pictures.

## Making a Folder to Save Pictures

When you make a folder on a card, pictures are thereafter saved in that folder. In this way you can manage pictures as you take them.



- 1 While pressing the mode lock (green), turn the power/mode dial to CAM mode.
- 2 Press the MENU button.  
The LCD monitor turns on and the menu is displayed.
- 3 Choose "New Folder" using the ▲(UP)/▼(DOWN) buttons.

CAMERA MENU	
Custom	
PC Card INIT	
User File Save	
<b>New Folder</b>	
ID Set	
File No. Mem	
WB Flash	
Date & Time	
LCD Set	
Display Set	

- 4 Press the EXECUTE button.

The message "Add No.xxxx Folder OK?" appears. [xxxx] is the automatically attached folder name.

- 5 Press the EXECUTE button.

The folder is created, and the camera is ready to take pictures.

Pictures are thereafter saved in that folder.

#### Note

You can create about 510 folders on a card.

## Attaching Keywords (ID Numbers) to Pictures


You can attach a keyword of up to 16 letters to a picture. The keyword is displayed when the picture is played back.

You can specify a keyword for a picture before taking it, or attach or change the keyword after the picture has been taken.

#### Note

You cannot attach a keyword to or change a keyword on a protected picture.

## Specifying a Keyword Before Shooting




- 1 While pressing the mode lock (green), turn the power/mode dial to CAM.

- 2 Press the MENU button.


The LCD monitor turns on, and the menu is displayed.

- 3 Select "ID Set" using the ▲(UP)/▼(DOWN) buttons.



- 4 Press the EXECUTE button.

The keyword screen is displayed.



- 5 Select "Mode" using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.

You can now change the mode setting.

- 6 Select "Off", "Hold" or "Inc" using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.

#### Off

Choose "Off" if you don't want to attach a keyword to a picture or to invalidate an existing keyword.

#### Hold

Choose "Hold" if you want to attach the same keyword to all pictures.

**Inc**

Choose “Inc” if you want the number of the picture to be automatically included at the end of keyword every time you take a picture.

(ex.) The keyword is PICTURE01

1st picture : PICTURE01

2nd picture : PICTURE02

}

9th picture : PICTURE09

10th picture : PICTURE10

**Note**

When the automatic counter reaches [99], the number returns to [00] the next time you take a picture.

The LCD monitor display returns to the keyword screen.

**7**

Choose “ID No.” using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.

You can now input a keyword.

**8**


Choose a letter to enter using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.

The letter you have chosen is input.

Repeat this step to enter the keyword. You can input up to 16 letters.

**Note**

Input begins from the 16th character space. If you want to input from a space in the middle, press the EXECUTE button until the cursor is automatically displayed in the correct place and then continue.




**9** If you finish inputting the keyword before reaching the 16-letter limit, move the cursor to END and press the EXECUTE button.

**10** Press the EXIT button.  
The display on the LCD monitor returns to the menu.

**11** Press the EXIT button.  
The menu disappears, and the camera is ready to take pictures.

## Adding or Changing a Keyword to a Picture that has Already been Taken



**1** While pressing the mode lock (green), turn the power/mode dial to PLAY.  
The LCD monitor turns on.

**2** Display the picture to which you want to add or change the keyword.

**3** Press the MENU button.  
The menu appears.

**4** Select "ID Set" using the ▲(UP)/▼(DOWN) buttons.

```
PLAY MENU
Rotate
D.Zoom
Auto Play
Protect
Delete
PC Card INIT
ID Set
LCD Set
Display Set
```

## 5 Press the EXECUTE button.

The keyword input screen is displayed.

If a keyword has already been attached to the picture, that keyword is displayed.

ID SET	P No.99
ID No. [0123456789012345]	
END BS CLR SPC	
0123456789! " # \$ % & ' ( ) * + , - . / : ; < = > ? [ \ ] ^ _ {   } ~	
ABCDEFGHIJKLMNOPQRSTUVWXYZ	
abcdefghijklmnopqrstuvwxyz	
0001/00009	

## 6 Choose the letter you'd like to enter using the ▲(UP)/▼(DOWN) buttons. Press the EXECUTE button.

The letter you have chosen is input.

Repeat this set to enter the keyword. You can input up to 16 letters.

### Note

If you want to enter the whole keyword again, set the cursor to CLR and press the EXECUTE button.

## 7 If you finish inputting the keyword before reaching the 16-letter limit, move the cursor to END and press the EXECUTE button.


The keyword is attached and the LCD monitor returns to the menu display. Proceed to step 9.

## 8 Press the EXIT button.

The keyword is attached and the LCD monitor returns to the menu display.

## 9 Press the EXIT button.

The menu disappears.




## Choosing a Method to Attach a File Name to a Picture

When a picture is taken, a number from 00001-99999 is automatically attached as a file name to the picture.

The following methods to attach a number are possible.

- Attach serial numbers on an individual card.
- Attach serial numbers consecutively, even if the card is changed.

### Specifying a File Number Before Shooting



- 1 While pressing the mode lock (green), turn the power/mode dial to CAM.
- 2 Press the MENU button.  
The LCD monitor turns on, and the menu is displayed.
- 3 Select "File No. Mem" using the ▲(UP)/▼(DOWN) buttons.

```
CAMERA MENU
Custom
PC Card INIT
User File Save
New Folder
ID Set
File No. Mem
WB Flash
Date & Time
LCD Set
Display Set
```

- 4 Press the EXECUTE button.  
The file name screen is displayed.

```
FILE NO. MEM          No. 99

Memory                off
Start No.             00001

                      100min
```

- 
- 5** Select “Memory” using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.

You can now change the “Memory” setting.

- 
- 6** Select either “off” or “on” using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.

**off**

Serial numbers are attached as file names on each card. When this method is selected, specifying a starting number is not possible.

**on**

Serial numbers are attached as file names and continue in consecutive order even if a new card is inserted. When this method is selected, you can specify a starting number.

**Note**

File names cannot be duplicated. When a card is inserted and pictures are recorded on that card, file names are attached starting with the next number from the number of the last recorded picture.

The LCD monitor display returns to the keyword screen.

- 
- 7** Choose “Start No.” using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.


You can now input a starting number.

- 
- 8** Specify a starting number using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.

**Note**

- You can specify a number within the range of 00001-99999. Specify a number larger than the number of the last recorded picture if pictures have been previously recorded on the inserted card.
- You cannot take any more pictures after file names have reached 99999. Insert a new card and specify a starting number other than 99999.





**9** Press the EXIT button.

The display on the LCD monitor returns to the menu.


**10** Press the EXIT button.

The menu disappears, and the camera is ready to take pictures.

## Miscellaneous Settings

The following settings are available with the digital still camera.

- Auto Power Off Function
- Interval Shooting (page 84)
- Review Function (page 86)
- Self-Timer
- Sharpness
- Histogram (page 86, 90)
- Frame
- Beep



**1** While pressing the mode lock (green), turn the power/mode dial to CAM.

**2** Press the MENU button.

The LCD monitor turns on and the menu is displayed.

**3** Choose "Custom" using the ▲(UP)/▼(DOWN) buttons.


```

CAMERA MENU
Custom
PC Card INIT
User File Save
New Folder
ID Set
File No. Mem
WB Flash
Date & Time
LCD Set
Display Set
    
```

4

Press the EXECUTE button.

The CUSTOM menu is displayed.



5

Choose the item you would like to set using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.

You can set the item you selected.

### Power Save (Auto Power Off Function)

- When set to ON, power to the LCD monitor is automatically turned off after approximately 1 minute (in CAM mode; approximately 3 minutes in PLAY mode) if the camera is not operated during that time, and power to the entire camera is turned off after approximately 4 more minutes (in CAM mode; approximately 2 more minutes in PLAY mode).
- When set to OFF, the power will not turn off over the passage of time.

### Interval Rec Time (Interval Shooting)

The interval in this function can be set within the range of 1 second to 99 hours, 59 minutes, 59 seconds (in one-second units).

Depending on the picture size and quality mode during shooting, the set interval may not be kept.

### Review (Automatic Review Function)

Sets the method of picture display directly after shooting.

- When set to ON, pictures are automatically displayed at the time of shooting. When the histogram setting is set to “Auto”, the histogram for that picture is also displayed. The display time is set in the REVIEW TIME setting.
- When set to “off”, the picture which was taken and its histogram are not automatically displayed.

**Note**

You can display the last picture taken at any time by pressing the REVIEW button.

**Review Time**

When Review is on or when the REVIEW button is pressed, the picture and/or histogram display time can be set for an interval within the range of 1 to 10 seconds (in one-second units).

**Self-Timer**

Sets the interval from when you press the RELEASE button to the time the shutter clicks within a range of 1 to 30 seconds (in one-second units).

**Sharpness**

Sets the sharpness of the outline of the recorded picture.

- When set to SOFT, the picture outline is gently blurred.
- When set to NORMAL, the picture is standard.
- When set to HARD, the picture edges are clearly outlined. Depending on the picture, noise may also be emphasized, resulting in a grainy appearance.

**Histogram**

Sets the display method for the histogram of a picture.

- When “Auto” is set, the histogram of a displayed picture is shown when the picture is taken with the review function “on” or when the REVIEW button is pressed.
- When “Manual” is set, the histogram of a picture is displayed by pressing the REVIEW button when that picture is being displayed with the review function.

**Note**

When the REVIEW button is pressed while a histogram is being displayed, the histogram disappears.

**Frame**


Selects the type of frame that is displayed on the LCD monitor.

Choose the item to be changed by pressing the ▲(UP)/▼(DOWN) buttons, then press the EXECUTE button to begin changing the item setting.


- “Type”

This item determines the type of frame displayed on the monitor.


Selecting “AE frame” selects the AE frame type. This frame shows the light metering area used for determining exposure. Note that metering is done in the same manner regardless of whether the AE frame is displayed.



Selecting the “Guide 90” frame changes frame display to guide lines that can be moved horizontally. These guide lines can be used to establish horizontal subject size and positioning within the frame.



Selecting the “Guide 0” frame changes frame display to guide lines that can be moved vertically. These guide lines can be used to establish vertical subject size and positioning within the frame.



- “Top”

The “Top” item is used for setting the position of the Guide 90 or Guide 0 guide line that is bisected by a crosshair. The guide line can be positioned anywhere between the points that are 1/10 of the monitor width from the sides (for the Guide 90 frame) or top and bottom (for the Guide 0 frame) of the monitor.

- “Bottom”

The “Bottom” item is used for setting the position of the Guide 90 or Guide 0 guide line without the crosshair. The guide line can be positioned anywhere between the points that are 1/10 of the monitor width from the sides (for the Guide 90 frame) or top and bottom (for the Guide 0 frame) of the monitor.

### Beep

With auto-focus photography, sets whether a beep sounds when the picture comes into focus upon pressing the release button.


- When “on” is set, a “beep” sounds when the picture comes into focus.
- When “off” is set, a “beep” does not sound.

- 
- 6** Set the value using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.

The LCD monitor display returns to the custom menu. If you want to continue, you can set another item at this time.

- 
- 7** Press the EXIT button.  
The LCD monitor display returns to menu.

- 
- 8** Press the EXIT button.  
The menu disappears and the camera is ready to take pictures.



## Shooting with the Flash


Use the flash when taking pictures in dark places, such as indoors.  
A flash is built-in in the unit.  
Depending on shooting conditions, choose a flash mode from among Auto, On, Off, and External.  
When shooting in the External mode, attach an external flash to the accessory shoe to take flash pictures.


### Flash Mode Usage Guide

Shooting Condition	Setting
Normal	Auto
The subject is lit from behind. You want to use a flash during daytime.	On
When you want to capture the natural lighting of candle-lit scenes, sunsets, etc. When you don't want the flash to go off accidentally.	Off

### Setting the Flash Mode

- 1
- While pressing the mode lock (green), turn the power/mode dial to CAM.
- 2
- Press the LCD button to turn the LCD monitor on.
- Note
- Settings can also be confirmed on the LCD panel.  
When checking the settings on the LCD panel, this step is not necessary.


- 3
- Turn the mode dial to  and press the shift button.
- This is the default mode.



### Note Concerning Use of the Built-in Flash

When photos are taken using the built-in flash, occlusion of light from the flash can occur under the following circumstances, resulting in a shadow at the bottom of the recorded image. If this occurs, change the zoom setting or use the optional external flash unit, as appropriate.


- When shots are taken at the wide-angle setting ( $f = 5.2$  mm)
- When shots are taken at the telephoto setting ( $f = 26$  mm) of a subject range of less than 1 meter
- When a lens hood or lens protection filter is attached to the lens



Flash pop-up key

4

While pressing the shift button, turn the shift dial to select a flash mode.



### Auto

In conditions of insufficient light, the flash automatically goes off. This is the default mode.

### On

Choose this mode when you want the flash to go off, for situations such as taking a picture of a subject that is backlit.

### Off

Choose this mode when you want to take a picture with natural lighting or you don't want a strobe effect in your picture.




### External

Choose this mode when you want to take a picture of a subject far from the camera and the light from the built-in flash is insufficient.

In such a case, attach an external flash to take pictures.

### Note

Flash modes are indicated on the LCD panel as

AUTO (Auto),  (On),  (Off), and  EXT (External).



5

Press the shift button.

The flash mode is set and the menu disappears.

Unless the shooting mode is set to manual exposure, the shutter speed indicator or the aperture indicator flashes when it is necessary to use the flash. When this happens, press the flash pop-up key to open the built-in flash, or attach an external flash to the accessory shoe.

If the flash mode is set to Auto or On, when the flash indicator flashes, the flash is warming up.  
When the flash lamp light becomes constant, the flash is ready for use.




### Note

When using the built-in flash, press the flash pop-up key to open it.  
When finished with the flash, push the top of the flash down to close.

## Adjusting White Balance when Taking Pictures with the Flash

You can adjust the white balance when using the flash.



- 1** While pressing the mode lock (green), turn the power/mode dial to CAM.
- 2** Press the MENU button.  
The LCD monitor turns on and the menu is displayed.
- 3** Select “WB Flash” using the ▲(UP)/▼(DOWN) buttons.


```

CAMERA MENU
Custom
PC Card INIT
User File Save
New Folder
ID Set
File No. Mem
WB Flash
Date & Time
LCD Set
Display Set
    
```



- 
- 4** Press the EXECUTE button.  
The WB FLASH menu is displayed.

- 
- 5** Select “Flash Mode” using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.



You can now set the flash mode.

- 
- 6** Choose “Internal” (built-in flash) or “External” (external flash) using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.  
  
Choose “Internal” to use the built-in flash or “External” to use the external flash and press the EXECUTE button.

- 
- 7** If you chose “External” in step 6, select “Interval” using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.

You can choose the interval during which to have the flash light.

Set an interval within the range of 3 to 10 seconds (in one-second units) using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.

**Note**

When using an external flash, set the amount of light for the flash before adjusting the white balance to avoid extreme brightness or darkness in your pictures.

- 
- 8** Point the camera toward a completely white subject until it completely fills the viewfinder.

- 9 Select “Start” using the ▲(UP)/▼(DOWN) buttons and then press EXECUTE.

“WB” is displayed in the viewfinder and white balance adjustment begins.

After the flash lights about 10 times, the WB indicator goes off. The white balance adjustment is complete.


The white balance value is valid until it is adjusted again.

#### Note

**When the WB indicator flashes, the white balance is not successfully being adjusted. Exit this mode by pressing any operation button besides the WB button and readjust the white balance again.**

## Continuous Shooting

In this mode you can continuously shoot pictures until you reach the maximum number by keeping the release button pressed.



- 1 While pressing the mode lock (green), turn the power/mode dial to CAM.

- 2 Turn the LCD monitor on by pressing the LCD button.


#### Note

Settings can also be confirmed on the LCD panel. When checking the settings on the LCD panel, this step is not necessary.

- 3 Turn the mode dial to DRIVE and press the shift button.

The DRIVE menu appears.

- 
- 4** While pressing the shift button, turn the shift dial to select “Cont1” or “Cont2.”



### Cont1

In this mode, when the shooting mode is set to a mode other than manual exposure, the exposure is automatically adjusted every time a picture is taken.

### Cont2

In this mode, the settings of the first picture are kept as pictures are taken in succession.

The continuous picture taking speed is faster in this mode than that in Cont1.

### Note

These modes are indicated on the LCD panel as 1 (Cont1) and 2 (Cont2).


- 
- 5** Release the shift button.

The continuous shooting mode is set, and the menu disappears. When taking pictures, keeping the release button pressed activates continuous shooting.

Auto focus will not work during continuous shooting. Set the focus before you start continuous shooting.

## Taking a Picture at Regular Intervals (Interval Shooting)

In this mode, after pressing the release button, pictures are continuously taken at regular intervals. How to set the shooting interval is described in the Miscellaneous Settings section (page 73).



**1** While pressing the mode lock (green), turn the power/mode lock to CAM.

**2** Press the LCD button to turn the LCD monitor on.


### Note

Settings can also be confirmed on the LCD panel. When checking the settings on the LCD panel, this step is not necessary.

**3** Turn the mode dial to DRIVE and press the shift button.

The DRIVE menu appears.

**4** While pressing the shift button, turn the shift dial to select "Interval Rec."



### Note

This option is indicated on the LCD panel as INT.

**5** Release the shift button.


The interval time is set, and the menu disappears. When you press the release button, interval shooting starts.

To stop interval shooting, set another shooting method besides interval shooting or set the power/mode dial to OFF or PLAY.

## Taking a Picture with the Self-Timer

In this mode, after pressing the release button, the shutter automatically clicks after a set period of time.

How to set the time between the pressing of the release button and the shutter release is described in the Miscellaneous Settings section (page 73).




- 1 While pressing the mode lock (green), turn the power/mode dial to CAM.
- 2 Press the LCD button to turn the LCD monitor on.

### Note

Settings can also be confirmed on the LCD panel. When checking the settings on the LCD panel, this step is not necessary.

- 3 Turn the mode dial to DRIVE and press the shift button.  
The DRIVE menu appears.

- 4 While pressing the shift button, turn the shift dial to select "Self Timer."



- 5 Release the shift button.  
The self-timer is set and the menu disappears. When you press the release button completely, the self-timer starts.

### Note

When taking photographs in the auto focus mode, press the release button halfway to focus, then press it all the way to take the shot.

## Checking Pictures Directly After Shooting (Review Funcion and Histogram)

When the REVIEW button is pressed directly after taking a picture, the picture is displayed on the LCD monitor in this mode.

When you turn the review function on in Miscellaneous Settings, pictures are displayed automatically, without having to press the REVIEW button.


Also, when histogram is set to “Auto” in “Miscellaneous Settings”, the histogram for a picture is displayed when that picture is displayed. When “Manual” is set, the histogram for a picture can be displayed by pressing the REVIEW button when that picture is displayed with the review function. When the REVIEW button is pressed while a histogram is being displayed, the histogram disappears.

### Histogram


A histogram is a bar graph which shows the distribution of brightness on a picture. The horizontal axis represents brightness and the vertical axis shows the number of pixels of each brightness level within a picture.

Generally, when a picture is overexposed, bars concentrate to the right of the graph. When a picture is underexposed, bars concentrate to the left of the graph. Use the histogram as a standard to determine the light exposure for a picture.


When Overexposed



When Properly Exposed



When Underexposed




#### Note

Depending on the picture, it may not be possible to display an accurate Histogram.

## Rotating the Picture

You can rotate the picture 90° clockwise or counter-clockwise, or 180° during playback.



- 1 While pressing the mode lock (green), turn the power/mode dial to PLAY.  
The LCD monitor turns on.

- 2 Push the MENU button.  
The menu is displayed on the LCD monitor.

- 3 Choose "Rotate" using the ▲(UP)/▼(DOWN) buttons.

```
PLAY MENU
Rotate
D.Zoom
Auto Play
Protect
Delete
PC Card INIT
ID Set
LCD Set
Display Set
```

- 4 Press the EXECUTE button.  
The ROTATE menu is displayed.

- 5 Choose an angle of rotation using the ▲(UP)/▼(DOWN) buttons and then press the EXECUTE button.

```
ROTATE
→ 90° cw
↶ 90° ccw
↓ 180°
```

### 90° cw (rotation of 90° to the right)

Rotates the picture 90° clockwise.


### 90° ccw (rotation of 90° to the left)

Rotates the picture 90° counter-clockwise.

### 180° (rotation of 180°)

Rotates the picture 180°.

The picture is displayed at the angle of rotation chosen.




- 6** Rotate the picture as described in step 5 as often as necessary.

- 7** Press the EXIT button.  
The LCD monitor returns to the menu display.  
Note, however, that information of rotation changes made to protected pictures is not saved.

- 8** Press the EXIT button.  
The menu disappears.

## Viewing an Enlarged Picture

You can view an enlarged detail of a picture during playback.



- 1** While pressing the mode lock (green), turn the power/mode dial to PLAY.

The LCD monitor turns on.

- 2** Press the MENU button.  
The menu is displayed on the LCD monitor.


- 3** Select "D. Zoom" using the ▲(UP)/▼(DOWN) buttons.

```
PLAY MENU
Rotate
D.Zoom
Auto Play
Protect
Delete
PC Card INIT
ID Set
LCD Set
Display Set
```



#### 4 Press the EXECUTE button.


The area of the picture to be enlarged is framed with a green line.



#### 5 Select the area to be enlarged using the ▲(UP)/▼(DOWN) buttons.


The frame moves left when the ▲(UP) button is pressed.

The frame moves right when the ▼(DOWN) button is pushed.




#### 6 Press the EXECUTE button.

The selected area is enlarged and displayed, and the position of the enlarged area is displayed in the upper left corner.



enlarged area



### Note

While viewing this screen, you can change the area to be enlarged by pressing the ▲(UP)/▼(DOWN) buttons.

**7**

Press the EXIT button.

The enlargement indicator is cancelled.

**8**

Press the EXIT button.

The menu returns to the LCD monitor display.

**9**

Press the EXIT button.

The menu disappears.


## Checking the Histogram of a Picture

When the REVIEW button is pressed while a picture is being displayed, the histogram for that picture is displayed.

# Advanced Operations Erasing

## Erasing All Pictures

You can erase all saved pictures that are no longer needed from the card. However, you cannot erase pictures that have been protected.



- 1 While pressing the mode lock (green), turn the power/mode dial to PLAY.

The LCD monitor turns on.

- 2 Press the MENU button.


The menu appears on the LCD monitor.

- 3 Select "Delete" using the ▲(UP)/▼(DOWN) buttons.

```
PLAY MENU
  Rotate
  D. Zoom
  Auto Play
  Protect
  Delete
  PC Card INIT
  ID Set
  LCD Set
  Display Set
```

- 4 Press the EXECUTE button.

The Delete menu appears.



- 5 Select "All" using the ▲(UP)/▼(DOWN) buttons and then press the EXECUTE button.

The message "Do you delete all images?" appears.

### Note

To cancel erase, press the EXIT button.

- 6 Press the EXECUTE buttons.

Picture erasing begins.


When deletion is finished, the LCD monitor display returns to the state shown in step 1.

### Caution

**Do not remove the card during picture deletion. Damage to the "Memory Stick" or PC Card may occur.**

## Erasing Selected Pictures

You can erase selected saved pictures, with the exception of protected pictures, from the card.



- 1 While pressing the mode lock (green), turn the power/mode dial to PLAY.  
The LCD monitor turns on.

- 2 Press the MENU button.  
The menu is displayed on the LCD monitor.

- 3 Choose "Delete" using the ▲(UP)/▼(DOWN) buttons.



```
PLAY MENU
Rotate
D.Zoom
Auto Play
Protect
Delete
PC Card INIT
ID Set
LCD Set
Display Set
```

- 4 Press the EXECUTE buttons.  
The Delete menu is displayed.

```
Delete
1 shot
Select
All
```


- 5** Choose “Select” using the ▲(UP)/▼(DOWN) buttons and then press the EXECUTE button.

The screen from which to choose pictures for deletion appears.



- 6** Turn the shift dial to the picture you would like to erase and press the EXECUTE button.

The chosen picture is marked.



#### Note

Protected pictures cannot be chosen.


- 7** Repeat step 6 to choose other pictures to be erased.

- 8** Press the ▼(DOWN) button.

The message “Do you delete x image(s)?” is displayed. [x] is the number of pictures chosen.

#### Note

To cancel deletion, press the EXIT button.



- 9** Press the EXECUTE button.

Picture erasing begins.

When deletion is finished, the LCD monitor returns to the state shown in step 5.

### Caution

**Do not remove the card during picture deletion. Damage to the “Memory Stick” or PC Card may occur.**

- 10** Press the EXIT button.

The LCD monitor display returns to the state shown in step 4.

- 11** Press the EXIT button.


The LCD monitor display returns to the menu.

- 12** Press the EXIT button.

The menu disappears.

## Erasing Pictures during Playback

You can erase pictures shown on the LCD monitor during playback. However, protected pictures cannot be erased.




- 1** While pressing the mode lock (green), turn the power/mode dial to PLAY.

The LCD monitor turns on.

- 2** Press the MENU button.


The menu is displayed on the LCD monitor.

- 3** Select “Delete” using the ▲(UP)/▼(DOWN) buttons.



- 4** Press the EXECUTE button.  
The Delete menu is displayed.

- 5** Select “1 Shot” using the ▲(UP)/▼(DOWN) buttons and then press the EXECUTE button.



The message “Do you delete this image?” appears.

#### Note

To cancel erase, press the EXIT button.


- 6** Press the EXECUTE button.

Picture erasing begins.

When deletion is finished, the LCD monitor returns to the state shown in step 4.

#### Caution

**Do not remove the card during picture deletion. Damage to the “Memory Stick” or PC Card may occur.**




- 7** Press the EXIT button.  
The LCD monitor display returns to the menu.

- 8** Press the EXIT button.  
The menu disappears.

## Making it Impossible to Erase Important Pictures (Protect)

You can save pictures from being accidentally erased. This is called “protecting” the picture. You can protect pictures when they are shown on the LCD monitor during playback.




- 1** While pressing the mode lock (green), turn the power/mode dial to PLAY.  
The LCD monitor turns on.
- 2** Press the MENU button.  
The menu is displayed on the LCD monitor.
- 3** Select “Protect” using the ▲(UP)/▼(DOWN) buttons.

```
PLAY MENU
Rotate
D. Zoom
Auto Play
Protect
Delete
PC Card INIT
ID Set
LCD Set
Display Set
```




## 4 Press the EXECUTE button.

The PROTECT menu is displayed.



## 5 Choose “1 Shot on/off” using the ▲(UP)/▼(DOWN) buttons and then press the EXECUTE button.

The chosen picture is protected, indicated by a P on the LCD monitor.



### Notes


- When you perform the same operation on a picture that has already been protected, the protect function is removed.
- When you select “All on” or “All off” from the PROTECT menu and press the EXECUTE button, all the pictures are protected, or protect is removed from all pictures.

## 6 Press the EXIT button.

The LCD monitor display returns to the menu.


## 7 Press the EXIT button.

The menu disappears.



## Setting the LCD Monitor Display

You can set whether or not information related to picture taking or playback is displayed on the LCD monitor.



- 1 While pressing the mode lock (green), turn the power/mode dial to CAM.

### Note

In this section, setting the LCD monitor display is explained while the power/mode dial is set to CAM, but the same operation can be done while the power/mode dial is set to PLAY.

- 2 Press the MENU button.

The LCD monitor turns on, and the menu is displayed.

- 3 Select "Display Set" using the ▲(UP)/▼(DOWN) buttons.

```
CAMERA MENU
Custom
PC Card INIT
User File Save
New Folder
ID Set
File No. Mem
WB Flash
Date & Time
LCD Set
Display Set
```

- 4 Press the EXECUTE button.

The display set menu appears.

- 5 Select the item you want to set using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.

The selected item is ready to change.

DISPLAY SET	
Size/Qlty/Rotate	on
Folder/File Name	on
ID No.	on
Date/Time	on
Remaining Shot	on
Tv/Av/Evcomp	on
Frame	on

- 6 Select “on” or “off” using the ▲(UP)/▼(DOWN) buttons and then press the EXECUTE button.

Items which can be set are listed below:

Size/Qlty/Rotate (Picture size/Picture quality/Rotation)

Folder/File Name

ID No. (Keyword)

Date/Time


Remaining Shot

Tv/Av/Evcomp (Shutter Speed/Aperture/EV compensation)

Frame

When each item is set to on or off, the LCD display returns to the state shown in step 3.

If you want to change the settings of other items, return to step 5 and repeat the same operation.



- 7 Press the EXIT button.


The LCD monitor display returns to the menu.

- 8 Press the EXIT button.

The menu disappears.

## Adjusting Picture Display on the LCD Monitor

Adjusts picture display items such as contrast, brightness, and display range on the LCD monitor.



- 1 While pressing the mode lock (green), turn the power/mode dial to PLAY.

The LCD monitor turns on.

### Note

In this section, adjusting the picture display is explained while the power/mode dial is set to PLAY, but the same operation can be done while the power/mode dial is set to CAM.

- 2 Press the MENU button.
- 3 Select "LCD Set" using the ▲(UP)/▼(DOWN) buttons.

```
PLAY MENU
Rotate
D. Zoom
Auto Play
Protect
Delete
PC Card INIT
ID Set
LCD Set
Display Set
```

- 4 Press the EXECUTE button.
- The LCD set menu is displayed.

- 5 Select an item using the ▲(UP)/▼(DOWN) buttons and then press the EXECUTE button.

You can set the chosen item.

```
LCD SET

Contrast      0
Bright        0
Color         0
Picture       0
Disp Area     Normal
```

- 6 Choose a value using the ▲(UP)/▼(DOWN) buttons and press the EXECUTE button.

The items you can set are listed below:

### Contrast, Bright, Color or Picture

Contrast, brightness, color density or picture sharpness can be set within a -10 to +10 range (in units of 1).


### Disp Area (Display area)

When NORMAL is chosen, the picture is displayed after being resized to fit the frame 100%.

When OVER is chosen, the picture is displayed without being resized.

When the values for the chosen items have been set, the LCD display returns to the state shown in step 5.

If you want to set another item, repeat the same operation from step 5.



- 7 Press the EXIT button.

The LCD monitor returns to the menu.

- 8 Press the EXIT button.


The menu disappears.

## Operation by Remote Control

Using the supplied remote control RM-S7D, you can perform the same operations as with the release button and shift dial operations on the camera itself.

The remote control is convenient when you want to take pictures without holding the camera or for playing back pictures on a television.

Further, when operating from a position where the camera cannot receive the remote control signal, connect the camera and remote control with the remote control cable (supplied).




### Note

The self-timer lamp on the front of the camera lights up briefly as signals from the remote control are received.

When you push the release button with the focus mode switch set to AF, the focus is automatically set before the picture is taken. There is a short time lag from the time you press the release button until the picture is taken.


If you want to take a picture without the time lag set the focus mode switch to MF. After manually adjusting the focus, press the release button to take the picture.

## Inserting the Battery into the Remote Control




1

Slide the battery cover in the direction of the ▲ mark while pushing the cover.




- 2 Insert a lithium button battery CR2025 into the battery case, making sure the + (plus) side is visible.



- 3 Return the battery cover to its original position.

## Connecting the remote control




- 1 Using the remote control cable (supplied), connect the remote control terminal on the camera to the corresponding terminal on the remote control.

### Note


When the remote control cable is connected to the remote control terminal, the remote control cannot operate as a wireless remote control. When you want to use the remote control as a wireless remote control, remove the remote control cable from the camera and the remote control RM-S7D.

## Using a Wall Socket


To take or play pictures without using the battery pack, plug the camera into a wall socket using the battery adaptor/charger AC-VQ800 (supplied) and DC power cable DK-415 (supplied with the AC-VQ800).



- 1** Slide the AC adaptor/charger's mode switch to video/camera.
- 2** Connect the DC and AC power cables to the AC adaptor/charger.
- 3** Make sure the power/mode dial on the camera is set to OFF.




- 4** Make sure the power/mode dial on the camera is set to OFF.



- 5** Slide the battery cover lock in the direction of the ▲ mark (a), and open the battery cover (b).
- 6** Remove the rubber from inside the battery cover.





**7** Insert the DC power cable connector ▲ mark side first into the battery case until it locks firmly into place.


**8** Put the cable into the battery cover groove and close the battery cover.

## Connecting to the PC


If the camera and the PC are connected using the PC interface cable (supplied), pictures stored on the PC card can be read by the PC and you can operate the camera from the PC.

### Note

- Before connecting the camera to the PC, please install the following hardware and software:
  - An IEEE1394 PCI board that conforms to OHCI standards (recommended: RATOC Systems, Inc. model type: RATOC-PCIFW1).
  - TWAIN driver software for Windows98 (supplied)  
Please refer to ReadMe on the driver setup CD-ROM for necessary system settings, installation procedures, and how to operate the TWAIN driver software.
- If the battery is disconnected during PC communication, images you have taken may be lost. When connecting to the PC, plug the AC adaptor/charger AC-VQ800 (supplied) into a wall socket.
- Place the card in the camera. Images are stored on the card even in PC mode.
- Please note that the camera may not work properly if it is connected through the standard 1394 (or 1394-compatible) interface that is provided with your computer.



**1** Connect the camera's PC interface terminal and the PC's IEEE1394 terminal using the PC interface cable (supplied).



2

While pressing the mode lock (green), turn the power/mode dial to the PC position.

Start the TWAIN driver software (supplied).

### Note

**The camera cannot be operated from the PC if the camera is being operated or the menu appears on the LCD monitor.**

- In PC mode, the LCD monitor turns OFF automatically after 15 seconds, even if it is set to ON.
- The menu displayed in PC mode is the same as that displayed in CAM mode. Make menu settings in the same way as in CAM mode.

# Menu Summary


There are three menus in the camera: Shooting Menu, Camera Menu, and Playback Menu.

## Mode Menu

The menu for setting shooting conditions. To call up this menu, turn the power/mode dial to CAM or PC\*, turn the mode dial and press the shift button.




\* The illustration above shows the monitor in CAM mode. When the monitor is in PC mode, PC appears in place of CAM.



## Exposure Mode

Sets the exposure. Choose from Program AE (Program), Aperture Priority AE (Aperture), Shutter Speed AE (Shutter) or Manual Exposure (Manual). → Page 51




## Flash

Sets the flash. Choose from Automatic Flash (Auto), On (On), Off (Off), or External Flash (External). → Page 78




## Picture Size

Sets the picture size. Choose from 1344 x 1024, 640 x 480, or x2 D. Zoom. → Page 53




## Picture Quality Mode

Sets the picture quality. Choose from Super, High, Middle, or Low. → Page 54




## White Balance Mode

Sets the method of white balance adjustment. Choose from Auto White Balance (Auto), White Balance Hold (Hold), Outdoor, or Indoor. → Page 57




## ISO Sensitivity

Sets the ISO sensitivity. Choose from ISO 50, 100 or 400. → Page 59



## User File

Resets setting content and reads the setting content that has been saved as user files. → Pages 63, 64



## Shooting Method








Sets the shooting method. Choose from Normal Shooting (1 Shot), Continuous Shooting 1 (Cont1), Continuous Shooting 2 (Cont2), Self-Timer, or Interval Shooting (Interval Timer). → Pages 82, 84, 85

## Camera Menu

The menu for setting the shooting conditions and camera functions. To call up the camera menu, turn the power/mode dial to the CAM or PC\* position and press the MENU button.



\* The illustration above shows the monitor in CAM mode. When the monitor is in PC mode, PC appears in place of CAM.



## Miscellaneous Settings

Sets each function of Auto Power Off, Interval Shooting, Review, Self-Timer, Sharpness, Histogram, Frame and Beep.  
→ Page 73

## Card Initialization

Initializes the card inserted in the camera.  
→ Page 31

## User File Save

Saves the content set by the mode dial and the content set in the custom menu as user files. Up to 3 user files can be saved.  
→ Page 63

## New Folder

Creates folders in which to save pictures.  
→ Page 65

## Keyword Setting

Attaches a keyword of up to 16 letters to a picture. → Page 66

## Choosing a Method to Attach a File Name


Selects whether to attach file names as serial numbers for each card or to attach file names as serial numbers that continue even if a card is changed. Specifying a starting number is possible. → Page 71

## White Balance Setting (with Flash Use)

Adjusts white balance when using a flash.  
→ Page 80

## Date and Time Setting

Uses a clock built-in to the camera to record the correct time and date.  
→ Page 27



**LCD Monitor Picture Display Fine Tuning**

Adjusts picture display items such as contrast, brightness, and display range on the LCD monitor. → Page 100




**LCD Monitor Display Setting**

Sets whether or not information necessary for shooting or playing back a picture such as picture size and Frame is displayed on the LCD monitor.

→ Page 98

## Playback Menu


The menu for setting different picture and playback options. To call up the menu, turn the power/mode dial to the PLAY position and press the MENU button.



## Picture Rotation


Rotates a picture 90° clockwise or counter-clockwise, or 180° during playback.

→ Page 87




## Picture Enlargement

Enlarges and displays a detail of a picture during playback. → Page 88




## Automatic Cycle Viewing

Pictures are played back one by one, automatically, on the screen. → Page 40




## Protect

Saves important pictures from being accidentally erased. This is called "protecting" the picture. → Page 96




## Erasing Pictures

Erases unnecessary pictures saved on a card. → Page 91




## Card Initialization

Initializes the card inserted in the camera. → Page 31



## Keyword Setting

Attaches a keyword of up to 16 letters to a picture. → Page 66



## LCD Monitor Picture Display Fine Tuning

Adjusts picture display items such as contrast, brightness, and display range on the LCD monitor. → Page 100

DISPLAY SET	
Size/Ø/tx/Rotate	on
Folder/File Name	on
ID No.	on
Date/Time	on
Remaining Shot	on
Tv/Av/Evcomp	on
Frame	on

## LCD Monitor Display Setting

Sets whether or not necessary information for picture taking or playback, such as picture size or Frame, is displayed on the LCD monitor. → Page 98

# Maintenance

---

---

## Maintenance of the Camera Surface

If the camera surface gets dirty, lightly wipe with a dry cloth. If the camera is very dirty, wipe with a cloth moistened with a small amount of neutral detergent and wipe dry.

- When using a chemical cleaning cloth, follow the manufacturer's instructions.
- Do not use volatile liquids such as alcohol, thinner or benzine on the camera surface. They will remove paint from the surface finish.

---

## Maintenance of the Lens Surface

Remove dust on the lens surface with a blower brush or soft cloth. If the lens is very dirty, wipe gently with a soft cloth or lens cleaning tissue, taking care not to scratch the lens surface.

---

## Condensation

Condensation may form on the lens when the camera is brought from a cold place to a warm place. There is no warning indicator to signal condensation on the lens. If you detect moisture, turn off the power and wait about one hour for the condensation to dissipate.



# Troubleshooting

Before bringing in your camera for servicing, check the following table as a guide to troubleshoot the problem. If the problem cannot be corrected, contact the place of purchase or your Sony dealer. If messages you are unfamiliar with appear in the viewfinder, or on the LCD panel or LCD monitor, refer to “Warning Indicators” on page 116.

Symptom	Cause	Corrective Action
Camera is inoperable.	Battery pack is empty. (battery warning indicator displays)	Charge the battery pack. (page 24)
	AC power adaptor/charger is not firmly connected.	Check the DC power cable and AC power cable connection. (page 104)
	Internal system is malfunctioning.	Disconnect the battery or power cable, wait one minute and reconnect. Turn the power on and check to make sure the camera is functioning correctly.
Power cuts out.	When the power/mode dial is set to CAM, monitor turns off if you don't operate it for about 1 minute (3 minutes in PLAY). Camera turns off completely if not operated for another 4 minutes (in CAM) or another 2 minutes (in PLAY).	Press the release button halfway or operate the power/function dial to restore power.
Battery power depletes quickly.	Battery pack is not charged enough.	Charge the battery fully. (page 24)
	Battery has reached the end of its life.	Replace it with a new chargeable lithium ion battery. (page 25)
Cannot take pictures.	Power/mode dial is not set to CAM.	Set the power/mode dial to CAM.
	The card has reached the picture taking limit.	Erase unnecessary pictures before taking more pictures. (page 91)
	The battery needs recharging.	Charge the rechargeable lithium ion battery. (page 24)


Symptom	Cause	Corrective Action
Auto focus does not work.	AF switch is set to MF (manual focus)	Set the AF switch to AF (auto focus).
	Pictures are being taken in conditions where auto focus does not work.	Manually set the focus. (page 37)
Picture is dark.	Subject is backlit. There is insufficient light.	Correct the brightness. (page 56)
When shooting a bright subject, vertical lines appear on the picture.	These lines are called “smears.”	The camera is not malfunctioning.
Black dots appear on LCD monitor or red, blue, and green dots cannot be erased.	Extremely precise technology is being used for the liquid crystal display.	The camera is not malfunctioning. The dots will not be recorded.
LCD display in the viewfinder is blurry.	The eyesight level is not properly adjusted.	Adjust the viewfinder focus to suit your eyesight. (page 33)
Picture is improperly exposed.	EV compensation is set.	Set the EV compensation to +/- 0 and try shooting again. (page 56)
	The camera is in shutter speed priority AE mode and has been set to an inappropriate speed.	Change the shutter speed to a more suitable speed using the shift dial. (page 51)
Picture is improperly exposed when using the flash.	The flash is too far from the subject.	Use the flash within a range of approx. 1.0 m to 2.5 m.
The flash does not work.	There is enough light, and the flash is not necessary. (when the flash is set to “Auto”)	When you want the flash to always go off, set it to “On”. (page 78)
	The flash is set to “Off”.	Set the flash to “Auto” or “On”. (page 78)

Symptom	Cause	Corrective Action
Picture is not recorded when you press the release button.	A card is not inserted in the camera.	Insert a card in the camera. (page 30)
	There are no more remaining shots.	Insert a new card.  Change the picture quality or erase unnecessary pictures. Check the remaining shot number and try again. (pages 54, 91)
	Files names for pictures recorded on the card have reached 99999.	Install a new card and specify a starting number other than 99999.
Vertical lines appear around lights or candle flames, etc., shot against a dark background.	This occurs when there is a strong contrast between the background and the subject.	The camera is not malfunctioning.
Auto focus does not work when shooting at night.	Auto focus may not work when taking pictures at night, or if the subject is dark.	Manually set the focus.
Camera will not play back.	Power/mode dial is not set to PLAY.	Set the power/mode dial to PLAY.
	The battery needs to be charged.	Charge the battery pack. (page 24)
	There are no pictures saved on the card.	Take a picture and save it on the card.
Cannot erase a picture.	The picture is protected or the card itself is write-protected.	Cancel the protect function. (page 96) If the card is write protected, turn the write-protect switch to OFF.
There is interference on the picture or LCD monitor.	The camera is near equipment with strong electromagnetic radiation, such as a TV.	Move the camera away from such equipment.


# Warning Indicators

## LCD Monitor


The following warning indicators appear on the LCD monitor.



### Low Battery Charge Indicator

When the battery voltage becomes low, the remaining battery time indicator on the LCD monitor changes to the  indicator.\*

\* When using the AC power adaptor/charger, this indicator does not appear.




### No Shot Available

If you press the release button when the picture file on the card is full, the message CARD FULL is displayed in red for 4 seconds.


To remove this indicator, erase pictures from the file or insert a new card.

## LCD Panel







The following warning indicators appear on the LCD panel.




### Battery Indicator

As the battery voltage becomes low,  is indicated on the LCD panel.

The battery indicator changes as follows:


Battery Indicator	Battery Charge Amount Standard (A fully charged battery is 100%)
	100 to 80%
	80 to 60%
	60 to 40%
	40 to 20%
	20 to 10%
 Flashing	Camera operation will stop within 1 minute. Change with a charged battery pack.

\* When using the AC power adaptor/charger, this indicator does not appear.



### No Shot Available display


When no further image files can be recorded on the file, the image number flashes to indicate that the card is full.



## EV Indicator

The letters EV appear whenever EV compensation mode is on.

When EV compensation is turned to +/- 0.0, the indicator does not appear.



## Auto Focus Off Indicator

When the AF switch is turned to MF (manual focus), the MF indicator appears.

# Error Messages

The following messages are displayed on the camera’s LCD monitor or LCD panel or in the viewfinder. Refer to list below for the meaning of the error message.

Message on LCD Panel or in Viewfinder	Message on LCD Monitor	Meaning and Corrective Action
Card	NO CARD	A card is not inserted. → Insert a card into the camera. (page 30)
Full	CARD FULL	The maximum number of pictures has been recorded on the card. → Erase unnecessary pictures (page 91) or insert a new card. (page 30)
Err03	IMAGE FULL	Number of created files on the card has reached 9999. → Erase unnecessary files (page 86) or insert a new card. (page 30)
Err04	IMAGE NO. FULL	Picture file names have reached 99,999. → Format card to save pictures on the computer (page 31) or insert a new card (page 30) and make sure the start number is not set to 99,999. (page 71)
Err05	FOLDER FULL	The maximum number of folders has been reached. → The maximum number of folders possible is 510. (page 65)
Err06	FOLDER NO. FULL	Folder names have reached 9,999. → Numbers above 9,999 cannot be attached to folder names.
Err08	ONLY 1 IMAGE	A card which had one or fewer pictures on it was attempted to be played back in cycle viewing mode. → After taking at least 2 pictures (page 33), try cycle viewing again. (page 39)
Err09	PROTECTED	A protected picture was attempted to be erased. → Cancel protect and try again. (page 96)
Err10	WRITE PROTECT	A picture was attempted to be taken or erased on a write-protected card. → Set the write-protect switch on the card to OFF and take or erase the picture.
Err11	NO ROTATION INFO	Rotation was attempted on a picture that was not recorded by the camera. → Only pictures recorded by the camera can be rotated. (page 87)

Message on LCD Panel or in Viewfinder	Message on LCD Monitor	Meaning and Corrective Action
Err12	NO ID INFO	A keyword was attempted to be added to a picture that was not recorded by the camera. → Keywords can only be added to pictures recorded by the camera. (page 66)
Err13	DATE & TIME NOT SET	The lithium button battery used to maintain the internal clock has run out. → Contact your nearest Sony dealer or Sony Customer Service. (page 28)
Err14	FORMAT ERROR	A card that cannot be used in the camera is inserted. → Initialize the card in the camera (page 31), or insert a card that can be used. (page 29)
Err15	READ ERROR	A picture that has not been recorded by the camera or has damaged data is attempted to be played back. → Play back a picture recorded by the camera or that is undamaged.
Err16	WRITE ERROR	The picture could not be recorded properly on the card. → Retake the picture.
—	BUSY	The card is being accessed. The indicator disappears when access is complete. → Wait until the indicator disappears.
—	NO IMAGE	A card on which no pictures had been recorded was attempted to be played back. → Take pictures on the card and try again. (page 33)



# Specifications

---

## System

---

Camera type	Digital still camera
Picture quality modes	Super – TIFF (Non compression) High, Middle, Low – JPEG (compression)
Recording medium	PCMCIA ATA TYPE II card Sony “Memory Stick” (for use with Memory Stick/PC Card Adapter)
Picture elements	1/2 inch single-plate, solid-state picture element (all elements read)  Total dot number: 1,500,000 pixels approx.
Optical viewfinder	Focusing screen with built-in double imaging, single ref type
LCD monitor	2.5" low-temperature, polysilicon TFT with 180,000 pixels
Minimum focal length	20 cm (focal distance for the whole area)
Aperture	F2 to F11 (wide angle) F2.4 to F11 (telephoto) variable
Shutter speed	4 to 1/2000 sec.  In AE mode, ISO 50 1/4 to 1/2000 sec. ISO 100 1/8 to 1/2000 sec. ISO 400 1/30 to 1/2000 sec.  combined use mechanical shutter and electric shutter
Continuous shooting speed	Maximum 2 frames/sec. (Picture quality mode is low, size is 640 × 480)
Lens	5× zoom  f = 5.2 to 26mm (equivalent to 28 to 140 for 35mm film cameras), 13 lens, 10 group, filter diameter: 62mm
Photographic sensitivity	ISO 50, 100, 400
Focus control	CCD TTL auto/manual focus mechanism
Light Meter	Center-weighted average light metering/Spot light metering, AE LOCK function
Exposure mode	Program AE, shutter speed priority AE, aperture priority AE, manual exposure
EV compensation	–2 to +2 EV (0.25 EV increments)

Internal flash	<p>External light sensor, self-adjusting system: adjusts to all shutter speeds</p> <p>Guide Number: GN10</p> <p>Range: 1.0 to 2.5 meters approx. (ISO 100, without EV compensation)</p> <p>Flash modes: Auto/On/Off</p>
White balance	Auto/One push hold/Indoor/Outdoor
Video output terminal	<p>NTSC model: 1.0Vp-p 75Ω, unbalanced, sync negative</p> <p>PAL model: 1.0Vp-p 75Ω, unbalanced, sync negative</p>
Accessory shoe	For use with external flash
Remote control terminal	For use with RM-S7D
PC interface (IEEE1394) terminal	400 Mbps, 6-pin, for connecting to a PC
Power source	Use with the "Info LITHIUM" battery NP-F550 (not supplied) or the AC power adaptor/charger AC-VQ800.
Power consumption	<p>For camera recording 0.9 A, DC7.2 V (when the LCD monitor is ON)</p> <p>For camera playback 0.6 A, DC7.2 V (When the LCD monitor is ON)</p> <p>When connected to the PC 0.95 A, DC7.2 V (When the LCD monitor is ON)</p>
Operating temperature	0°C to +40°C (32°F to 104°F)
Storage temperature	-20°C to +60°C (-4°F to 140°F)
Dimensions	<p>130 × 100 × 150mm</p> <p>(5 1/5 × 4 × 6 inches) (W × H × L)</p>
Mass	Approx. 900g (not including battery pack and PC card)

---

## Accessories

Viewfinder cap (fitted on the lens, 1)  
Lens cap (fitted on the lens, 1)  
Video cable (1)  
Wireless remote control (1)  
Remote control cable (5 meters, 1)  
AC adaptor/charger AC-VQ800 (DK-415 supplied with the AC-VQ800, 1)  
PC interface cable (1)  
“Memory Stick” (1)  
Memory Stick/PC Card Adaptor (1)  
TWAIN Driver Software CD-ROM (1)  
User’s manual (this manual, 1)  
Warranty (1)

Design and specifications are subject to change without notice.

# Index

---

## A

AE-LOCK .....	36
Aperture .....	51
Aperture Priority AE .....	51
Auto Focus .....	35
Auto Power Off Function .....	73
Automatic Cycle Viewing .....	39, 40

## B

Battery .....	24, 25
Battery Cover Lock .....	26
Battery Indicator .....	116, 117
Battery Pack Charging Time .....	24
Battery Pack Continuous Use Time .....	24
Battery Pack Installation .....	25
Beep .....	73

## C

Card .....	29
Charging the Battery .....	24
Continuous Shooting .....	82

## D

Date & Time Setting .....	27
Display Set .....	98

## E

Enlargement .....	88
Erasing a Picture .....	91
EV Compensation .....	56
EV compensation .....	56

## F

Folders .....	65
Frame .....	23, 73

## H

Histogram .....	73, 90
-----------------	--------

## I

i.LINK cable .....	13
i.LINK terminal .....	13
Index Display .....	39
Initialization .....	31
Interval Shooting .....	73, 84
ISO (Photographic) Sensitivity .....	59

## K

Keyword .....	66
---------------	----

## L

LCD Monitor .....	100
LCD Set .....	100
Lens cap .....	10
Light Meter Method .....	60
Lithium Button Battery .....	28

## M

Maintenance .....	112
Manual Exposure .....	51
Manual Focus .....	37
Memory Stick .....	29
Memory Stick/PC Card Adaptor .....	29
Menus .....	107

## P

Picture Quality Mode .....	54
Picture Size .....	53
Playback .....	39, 87
Power Save .....	74
Program AE .....	51
Protect Function .....	96

## R

Reading Setting Content .....	64
Remote Control .....	102
Remote Control Cable .....	19, 102
Resetting Settings Content .....	62
Review Function and Histogram .....	86
Review Function .....	73
Rotation .....	87

## S

Saving User Files .....	63
Self-Timer .....	73, 85
Sharpness .....	73
Shutter Speed .....	51, 52
Shutter Speed Priority AE .....	52

## T

Taking a Picture .....	33, 78
Tripod .....	20
Troubleshooting .....	113
TWAIN Driver Software .....	105

## V

Viewfinder Cap .....	32
Viewing by Index .....	39
Viewing in Succession .....	39
Viewing on a Television .....	44

## W

Wall Socket .....	104
Warning Indicators .....	116
White Balance .....	80
White Balance Adjustment .....	57

## Z

Zoom .....	34
------------	----





For information regarding the DKC-FP3, please see  
our Internet home page at  
<http://www.world.sony.com/DKC-FP3>

---

Sony  line <http://www.world.sony.com/>

---